



LBE-5AC-LR Quick Start Guide

Click for [×]
Table of Contents **ntents**



Antenna Feed



Center Reflector Panel



Side Reflector Panels (Qty. 2)



Mounting Bracket



Feed Receiver



Pivot Panels (Qty. 2)



M4 SEM Screws (Qty. 8)



M8 SEM Screws (Qty. 4)



Metal Straps (Qty. 3)



Gigabit PoE (24V, 0.3A) with Mounting Bracket



Power Cord

LBE-5AC-LR Quick Start Guide

- Phillips screwdriver


Click for

Table of Contents rench or screwdriver

- Shielded Category 5 (or above) cabling with drain wire should be used for all wired Ethernet connections and should be grounded through the AC ground of the PoE.

We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from Ubiquiti. For more details, visit ui.com/toughcable

- Surge protection should be used for all outdoor installations. We recommend that you use two Ethernet Surge Protectors, model ETH-SP, one near the LiteBeam and the other at the entry point to the building. The ETH-SP will absorb power surges and safely discharge them into the ground.



Application Examples

The LiteBeam AC mounted outdoors with the reflector installed provides directional outdoor coverage (gain reflector-dependent).



LBE-5AC-LR Quick Start Guide

Click for
Table of Contents



The LiteBeam AC mounted outdoors without the reflector installed provides outdoor-to-indoor coverage using the 3 dBi Antenna Feed only.



Hardware Overview

LBE-5AC-LR Quick Start Guide



Click for ×
Table of Contents



1 Ethernet LED
The LED will light steady blue when an active Ethernet connection is made and flash when there is activity.
2 Power LED
The LED will light blue when the device is connected to a power source.
3 Reset Button
To reset to factory defaults, press and hold the Reset button for more than 10 seconds while the LiteBeam AC is powered on. The LiteBeam AC may also be reset remotely using the auxiliary Reset button located on the bottom of the Gigabit PoE adapter.
4 Ethernet Port
Supports 10/100/1000 connections and passive PoE. This port should be connected to the LAN and DHCP server.

Hardware Installation


1.



Click for
Table of Contents

×

LBE-5AC-LR Quick Start Guide




2.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents

×



3.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents

×



4.



Click for
Table of Contents

×

LBE-5AC-LR Quick Start Guide



5.




6.



Click for
Table of Contents

LBE-5AC-LR Quick Start Guide



7.



8.



Click for
Table of Contents

×

LBE-5AC-LR Quick Start Guide



9.



10.



Click for
Table of Contents


×

LBE-5AC-LR Quick Start Guide



Pole Mounting

1.




2.

LBE-5AC-LR Quick Start Guide




Click for
Table of Contents

×



3.




4.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents




5.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents

×



6.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents

x



Connecting Power




WARNING: The switch port must comply with the power specifications listed in this Quick Start Guide.

LBE-5AC-LR Quick Start Guide

Click for
Table of Contents



OR



Optional



Accessing airOS via Wi-Fi

Verify connectivity in the airOS® Configuration Interface using the UNMS™ app or Web Portal. Both are available for 15 minutes immediately after you power on the device. If necessary, you can power cycle the device to re-enable its Wi-Fi.

UNMS App

1. Download the UNMS app.

LBE-5AC-LR Quick Start Guide



Click for
Table of Contents

2. Connect your device's Wi-Fi to the SSID named: <model>:<MAC Address>



Note: Ensure that DHCP is enabled on your Wi-Fi adapter.

3. Launch the app and follow the on-screen instructions.

Web Portal

1. Connect your device's Wi-Fi to the SSID named: <model>:<MAC Address>



Note: Ensure that your Wi-Fi connection has DHCP enabled.

2. Launch your web browser and go to: <http://setup.ui.com>



3. Select your Country and Language. You must agree to the Terms of Use to use the product. Click Continue.

LBE-5AC-LR Quick Start Guide

Click for
Table of Contents


The airOS Configuration Interface will appear, allowing you to customize your settings as needed. For additional details, refer to the User Guide available at ui.com/download/airmax-ac

Installer Compliance Responsibility

Devices must be professionally installed and it is the professional installer's responsibility to make sure the device is operated within local country regulatory requirements.



LBE-5AC-LR Quick Start Guide

Click for  a from the list. If Calculate EIRP Limit is enabled, transmit automatically adjusted to comply with the regulations of the Table of Contents For a Custom antenna, Antenna Gain is entered manually. Note the requirements and antenna types listed below.

Cable Loss (When applicable)

Enter the cable loss in dB. Output power is adjusted to compensate for loss between the radio and the antenna.

Certified Antenna Types

This radio transmitter FCC ID: SWX-LBE5ACLR / IC: 6545A-LBE5ACLR has been approved by FCC / ISED Canada to operate with the antenna types listed below with the maximum permissible gain for each antenna type indicated. Antenna types not included in this list or having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Antenna	Frequency	Gain
Grid	5 GHz	26 dBi

Specifications

LBE-5AC-LR	
Dimensions	512.5 x 385.75 x 258.3 mm (20.18 x 15.19 x 10.17")
Weight	
With Mount	1.360 kg (2.998 lb)
Without Mount	1.735 kg (3.825 lb)
Networking Interface	(1) 10/100/1000 Ethernet Port
Antenna Gain	26 dBi
Max. Power Output	25 dBm
Max. Power Consumption	7W
Power Supply	24V, 0.3A Gigabit PoE Adapter
Power Method	Passive PoE (Pairs 4, 5+; 7, 8 Return)
Operating Temperature	-40 to 70° C (-40 to 158° F)
Operating Humidity	5 to 95% Noncondensing
ESD/EMP Protection	± 24 kV Contact / Air
Shock and Vibration	ETSI300-019-1.4
Wind Survivability	200 km/h (125 mph)



Wind Loading

LBE-5AC-LR Quick Start Guide

 550 IN @ 200 MPH
 (123.6 lbf @ 125 mph)

 Click for
 Table of Contents

×

CE, FCC, IC

Operating Frequency (MHz)		
Worldwide		<u>5150 - 5875</u>
US/CA	U-NII-1	<u>5150 - 5250</u>
	U-NII-2A	<u>5250 - 5350</u>
	U-NII-2C	<u>5470 - 5725</u>
	U-NII-3	<u>5725 - 5850</u>
Management Radio (MHz)		
Worldwide		<u>2412 - 2472</u>
US/CA		<u>2412 - 2462</u>

Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.

LBE-5AC-LR Quick Start Guide

e. Protective bonding must be installed in accordance with local national wiring rules and

Click for
Table of Contents

anty

ui.com/support/warranty

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This radio transmitter has been approved by FCC.

ISED Canada

CAN ICES-3(A)/NMB-3(A)

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This radio transmitter has been approved by ISED Canada.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

CAN ICES-3(A)/NMB-3(A)

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :



susceptible d'en compromettre le fonctionnement.

Click for ^x audio a été approuvé par ISDE Canada.

Table of Contents

Table of Contents

Quant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

IMPORTANT NOTE

Radiation Exposure Statement

- This equipment complies with radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with minimum distance 103 cm between the radiator and your body.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

AVIS IMPORTANT

Déclaration sur l'exposition aux rayonnements

- Cet équipement est conforme aux limites prévues pour l'exposition aux rayonnements dans un environnement non contrôlé.
- Lors de l'installation et de la mise en fonctionnement de l'équipement, assurez-vous qu'il y ait une distance minimale de 103 cm entre l'élément rayonnant et vous.
- Cet émetteur ne doit être installé à proximité d'aucune autre antenne ni d'aucun autre émetteur, et ne doit être utilisé conjointement à aucun autre de ces appareils.

Australia and New Zealand



Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

Brazil



Nota: Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



Country List

[illegible]

LBE-5AC-LR Quick Start Guide

× BFWA (Broadband Fixed Wireless Access) members noted in blue

Click for
Table of Contents

Device meets Max. TX power limit per ETSI regulations.

The following apply to products that operate in the 5 GHz frequency range:



Note: This device is restricted to indoor use only when operating in the 5150 - 5350 MHz frequency range within all member states.



Note: Operation in the 5.8 GHz frequency band is prohibited in BFWA member states. Other countries listed may use the 5.8 GHz frequency band.

WEEE Compliance Statement

Declaration of Conformity

Online Resources



© 2021 Ubiquiti Inc. All rights reserved.