

**Content**

LIST OF FIGURES ..... 4

LIST OF TABLES..... 7

DESCRIPTION OF THE GPRS/EDGE/HSDPA ROUTER ..... 8

    Examples of Possible Application ..... 8

    Technical Parameters ..... 9

    GWR Router features..... 10

    Product Overview ..... 11

*Front panel* ..... 11

*Back panel* ..... 11

*Top Panel* ..... 12

    Putting Into Operation ..... 13

    Declaration of conformity ..... 14

DEVICE CONFIGURATION..... 15

DEVICE CONFIGURATION USING WEB APPLICATION ..... 15

    Add/Remove/Update manipulation in tables..... 16

    Save/Reload changes ..... 16

    Status Information ..... 16

    Status - General ..... 16

    Status - Network Information ..... 17

    Status - WAN Information ..... 17

    Settings - Network ..... 19

    Settings - DHCP Server ..... 20

    Settings - WAN Setting..... 22

    Settings - Routing..... 25

*Port translation* ..... 27

    Settings - Dynamic Routing Protocol..... 27

*Routing Information Protocol (RIP)*..... 27

            RIP routing engine for the GWR Router..... 28

    Settings - VPN Settings ..... 30

*Generic Routing Encapsulation (GRE)* ..... 30

*GRE Keepalive*..... 31

*Internet Protocol Security (IPSec)*..... 32

    Settings - IP Filtering ..... 37

*IP Filtering configuration example*..... 39

    Maintenance ..... 40

        Maintenance - Administrator Password ..... 40

        Maintenance - Device Identity Settings ..... 41

        Maintenance - Date/Time Settings..... 42

        Maintenance - Diagnostics..... 44

        Maintenance - Update Firmware ..... 44

        Maintenance - Settings Backup ..... 45

*Import Configuration File*..... 45

*Export Configuration File*..... 45

        Maintenance - System Reboot ..... 46

        Maintenance - Default Settings ..... 47

    Management - Serial Port..... 47

    Management - Simple Management Protocol (SNMP) ..... 49

    Management - Logs ..... 50

    Wizards - Internet Access ..... 52

    Wizards - GRE Tunnel..... 53

    Wizards - IPSec Tunnel ..... 55

    Logout ..... 59

DEVICE CONFIGURATION USING CONSOLE .....	59
Network Settings.....	60
<i>Static vs. Dynamic IP Addresses</i> .....	60
DHCP Server Settings .....	61
GPRS/EDGE/HSDPA Settings.....	61
Routing.....	62
Administration .....	63
Status .....	64
General System Information .....	64
Network Information.....	65
GPRS/EDGE Information .....	66
Configuration Wizard .....	67
CONFIGURATION EXAMPLE.....	68
GWR Router as Internet Router .....	68
GRE Tunnel configuration between two GWR Routers.....	69
GRE Tunnel configuration between GWR Router and third party router .....	74
IPSec Tunnel configuration between two GWR Routers.....	78
IPSec Tunnel configuration between GWR Router and Cisco Router .....	85
IPSec Tunnel configuration between GWR Router and Juniper SSG firewall.....	91
APPENDIX .....	105
A. How to Achieve Maximum Signal Strength with GWR Router?.....	105
<i>Antenna placement</i> .....	105
<i>Antenna Options</i> .....	105
B. Mobile operator GPRS settings.....	106
Australia.....	106
Austria.....	106
Belgium .....	106
Brasil .....	106
Canada.....	106
China .....	107
Croatia .....	107
Czech Republic .....	107
Denmark .....	107
Egypt .....	107
Estonia.....	107
Finland .....	107
France.....	108
Germany.....	108
Greece .....	108
Hongkong .....	108
Hungary .....	109
India .....	109
Indonesia .....	109
Ireland .....	109
Israel.....	109
Italy .....	110
Japan.....	110
Lithuania .....	110
Luxembourg.....	110
Macedonian .....	110
Malaysia .....	110
Mexico .....	111
Netherlands .....	111
New Zeleand.....	111
Norway.....	111
Poland.....	111
Phillipines.....	111
Portugal.....	111
Russia.....	112

---

<i>Serbia</i> .....	112
<i>Singapore</i> .....	112
<i>Slovakia</i> .....	112
<i>Slovenia</i> .....	112
<i>South Africa</i> .....	112
<i>Spain</i> .....	112
<i>Sweden</i> .....	113
<i>Switzerland</i> .....	113
<i>Taiwan</i> .....	113
<i>Thailand</i> .....	113
<i>Turkey</i> .....	113
<i>UK</i> .....	113
<i>Ukraine</i> .....	114
<i>USA</i> .....	114

## List of Figures

Figure 1 - GWR Router .....	8
Figure 2 - GWR Router front panel .....	11
Figure 3 - GWR Router back panel .....	11
Figure 4 - GWR Router top panel side .....	12
Figure 5 - Declaration of conformity.....	14
Figure 6 - User authentication .....	15
Figure 7 - General Router information .....	17
Figure 8 - Network Information .....	18
Figure 9 - WAN Information .....	18
Figure 10 - Network parameters configuration page .....	19
Figure 11 - DHCP Server configuration page.....	21
Figure 12 - WAN Settings configuration page .....	22
Figure 13 - Routing configuration page .....	25
Figure 14 - RIP configuration page .....	27
Figure 15 - GRE tunnel parameters configuration page .....	31
Figure 16 - IPSec Summary screen.....	32
Figure 17 - IPSec Settings part I.....	33
Figure 18 - IPSec Settings part II.....	34
Figure 19 - IP Filtering configuration page.....	38
Figure 20 - IP Filtering configuration example.....	39
Figure 21 - IP Filtering settings.....	39
Figure 22 - Administrator Password configuration page .....	40
Figure 23 - Device Identity Settings configuration page .....	42
Figure 24 - Date/Time Settings configuration page .....	42
Figure 25 - Diagnostic page.....	44
Figure 26 - Update Firmware page .....	45
Figure 27 - File download .....	46
Figure 28 - System Reboot page .....	46
Figure 29 - Default Settings page .....	47
Figure 30 - Serial Port configuration page .....	48
Figure 31 - SNMP configuration page.....	50
Figure 32 - Syslog configuration page .....	51
Figure 33 - Internet Access Wizard - page 1 of 3.....	52
Figure 34 - Internet Access Wizard - page 2 of 3.....	52
Figure 35 - Internet Access Wizard - page 3 of 3.....	53
Figure 36 - GRE Tunnel Wizard - 1 of 4 .....	53
Figure 37 - GRE Tunnel Wizard - 2 of 4 .....	54
Figure 38 - GRE Tunnel Wizard - 3 of 4 .....	54
Figure 39 - GRE Tunnel Wizard - 4 of 4 .....	55
Figure 40 - IPSec Tunnel Wizard - 1 of 6 .....	55
Figure 41 - IPSec Tunnel Wizard - 2 of 6 .....	56
Figure 42 - IPSec Tunnel Wizard - 3 of 6 .....	57
Figure 43 - IPSec Tunnel Wizard - 4 of 6 .....	57
Figure 44 - IPSec Tunnel Wizard - 5 of 6 .....	58
Figure 45 - IPSec Tunnel Wizard - 6 of 6 .....	58
Figure 46 - Default serial port parameters .....	59
Figure 47 - Login menu .....	59
Figure 48 - Main configuration menu.....	60
Figure 49 - Network parameters .....	60
Figure 50 - Network parameters configuration.....	61
Figure 51 - DHCP Server configuration .....	61
Figure 52 - Primary DNS.....	61

Figure 53 - Secondary DNS ..... 61

Figure 54 - SIM card selection ..... 62

Figure 55 - SIM card GSM/UMTS configuration ..... 62

Figure 56 - GSM/UMTS authentication ..... 62

Figure 57 - Routing menu ..... 62

Figure 58 - Routing table (list of all routes) ..... 63

Figure 59 - Administration Menu ..... 63

Figure 60 - Administrator password ..... 63

Figure 61 - Network diagnostic utility ..... 63

Figure 62 - Date/time parameters ..... 64

Figure 63 - List of Restore option ..... 64

Figure 64 - Status Menu ..... 64

Figure 65 - List of basic system parameters ..... 65

Figure 66 - Status of LAN network connection ..... 66

Figure 67 - GSM/UMTS status ..... 67

Figure 68 - Configuration wizard ..... 67

Figure 69 - GWR Router as Internet router ..... 68

Figure 70 - GRE tunnel between two GWR Routers ..... 69

Figure 71 - Network configuration page for GWR Router 1 ..... 70

Figure 72 - GRE configuration page for GWR Router 1 ..... 71

Figure 73 - Routing configuration page for GWR Router 1 ..... 71

Figure 74 - Network configuration page for GWR Router 2 ..... 72

Figure 75 - GRE configuration page for GWR Router 2 ..... 73

Figure 76 - Routing configuration page for GWR Router 2 ..... 73

Figure 77 - GRE tunnel between Cisco router and GWR Router ..... 74

Figure 78 - Network configuration page ..... 76

Figure 79 - GRE configuration page ..... 77

Figure 80 - Routing configuration page ..... 77

Figure 81 - IPSec tunnel between two GWR Routers ..... 78

Figure 82 - Network configuration page for GWR Router 1 ..... 79

Figure 83 - IPSEC configuration page I for GWR Router 1 ..... 80

Figure 84 - IPSec configuration page II for GWR Router 1 ..... 80

Figure 85 - IPSec start/ stop page for GWR Router 1 ..... 81

Figure 86 - Network configuration page for GWR Router 2 ..... 82

Figure 87 - IPSEC configuration page I for GWR Router 2 ..... 83

Figure 88 - IPSec configuration page II for GWR Router 2 ..... 83

Figure 89 - IPSec start/ stop page for GWR Router 2 ..... 84

Figure 90 - IPSec tunnel between GWR Router and Cisco Router ..... 85

Figure 91 - Network configuration page for GWR Router ..... 86

Figure 92 - IPSEC configuration page I for GWR Router ..... 87

Figure 93 - IPSec configuration page II for GWR Router ..... 88

Figure 94 - IPSec start/ stop page for GWR Router ..... 88

Figure 95 - IPSec tunnel between GWR Router and Cisco Router ..... 91

Figure 96 - Network configuration page for GWR Router ..... 92

Figure 97 - IPSEC configuration page I for GWR Router ..... 93

Figure 98 - IPSec configuration page II for GWR Router ..... 94

Figure 99 - IPSec start/ stop page for GWR Router ..... 94

Figure 100 - Network Interfaces (list) ..... 95

Figure 101 - Network Interfaces (edit) ..... 95

Figure 102 - AutoKey Advanced Gateway ..... 96

Figure 103 - Gateway parameters ..... 97

Figure 104 - Gateway advanced parameters ..... 98

Figure 105 - AutoKey IKE ..... 99

Figure 106 - AutoKey IKE parameters ..... 100

Figure 107 - AutoKey IKE advanced parameters ..... 101

---

Figure 108 - Routing parameters ..... 102  
Figure 109 - Policies from untrust to trust zone ..... 103  
Figure 110 - Policies from trust to untrust zone ..... 104

## List of Tables

Table 1 - Technical parameters .....	9
Table 2 - GWR Router features .....	10
Table 3 - Network parameters .....	19
Table 4 - DHCP Server parameters .....	20
Table 5 - WAN parameters .....	23
Table 6 - Advanced WAN Settings .....	24
Table 7 - Routing parameters.....	26
Table 8 - RIP parameters .....	28
Table 9 - GRE parameters.....	31
Table 10 - IPSec Summary .....	33
Table 11 - IPSec Parameters .....	36
Table 12 - IP filtering parameters .....	38
Table 13 - Administrator password .....	41
Table 14 - Device Identity parameters .....	41
Table 15 - Date/time parameters .....	43
Table 16 - Serial port parameters.....	49
Table 17 - SNMP parameters .....	50
Table 18 - Syslog parameters .....	51

## Description of the GPRS/EDGE/HSDPA Router

Thank you for choosing Geneko GWR Router. The GWR Router is a compact electronic device based on different kind of GSM/UMTS modules which enables data transfers using GPRS/EDGE/HSDPA technologies. Primarily, the GWR Router expands the capabilities of GSM/UMTS module by the option of connecting entire LAN through the built-in Ethernet interface. The GWR Router provides automatic establishment and maintenance of GPRS/EDGE/HSDPA connection. Integrated DHCP server provides the users simple installation procedure and fast Internet access. Built-in VPN server provides VPN capabilities like GRE server/client, VPN IPSec/GRE pass through and VPN IPSec.



Figure 1 - GWR Router

### Examples of Possible Application

- mobile office;
- fleet management;
- security system;
- telemetric;
- remote monitoring;
- vending and dispatcher machines;

## Technical Parameters

<b>Complies with standards</b>	EMC	Directive 2004/108/EC
		EN 301 489-1 V1.6.1(2005-09)
		EN 301 489-7 V1.3.1(2005-11)
	LVD	EN 60950-1:2001(1st Ed.) and/or EN 60950-1:2001
	R&TTE	Directive 1999/05/EC
		ETSI EN 301 511 V9.0.2 EN 301 908-1 & EN 301 908-2(v2.2.1)
RoHS	Directive 2002/95/EC	
	EU Commission 2005/618/EC, 2005/717/EC, 2005/747/EC, 2006/310/EC, 2006/690/EC, 2006/691/EC and 2006/692/EC	
<b>Ethernet interface</b>	Connector RJ-45 Standard: IEEE 802.3 Physical layer: 10/100Base-T Speed: 10/100Mbps Mode: full or half duplex	
<b>Other interfaces</b>	1 x UART(RS-232C) 1 x USB Host	
<b>RF characteristics of GSM module</b>	GPRS	Tri-band: 900/1800/1900 GPRS multi-slot class 10, mobile station class B
	GPRS EDGE	Quad band: GSM 850/900/1800/1900MHz EDGE multi-slot class 10, mobile station class B GPRS multi-slot class 12, mobile station class B
	GPRS EDGE UMTS HSDPA	UMTS/HSDPA: Triple band, 850/1900/2100MHz GSM/GPRS/EDGE: Quad band, 850/900/1800/1900MHz GPRS multi-slot class 10, mobile station class B EDGE multi-slot class 10, mobile station class B
<b>RF Connector</b>	SMA, 50Ω	
<b>Status LED</b>	Ethernet activity / network traffic Power on GSM link activity / attached network(GSM, UMTS) Signal quality	
<b>Power supply</b>	9 - 12VDC / 1000mA	
<b>Temperature range</b>	Operation: -5°C to +50°C Storage: -20°C to +85°C	
<b>Physical characteristics</b>	Width x Length x Height = 95 x 135 x 35 mm Weight 380g	

Table 1 - Technical parameters

\*Advanced version: GWR201, GWR202, GWR251, GWR252, GWR301, GWR302

\*\*Base version: GWR201-B, GWR202-B, GWR251-B, GWR252-B

## GWR Router features

<i>Feature</i>	<i>Short description</i>	<i>Base version*</i>	<i>Advanced version**</i>
<b>Main Ethernet Configuration</b>			
<b>Static IP / DHCP Client</b>	Static and dynamic IP address	√	√
<b>DHCP Server</b>	DHCP Server support	√	√
<b>Routing</b>	Static	√	√
<b>IP filtering</b>	IP address / Network filtering	√	√
<b>NAT</b>	NAT on WAN interface	√	√
<b>IP forwarding</b>	IP, TCP, UDP packets from WAN to LAN	√	√
<b>GRE</b>	Generic Routing Encapsulation is a tunneling protocol that can encapsulate a wide variety of network layer protocol packet types inside IP tunnels	√	√
<b>GRE Keepalive</b>	Keepalive for GRE tunnels	√	√
<b>IPSec pass-through</b>	ESP tunnels	√	√
<b>IPsec</b>	Internet Protocol Security is a suite of protocols for securing IP communications by authenticating and encrypting each IP packet of a data stream	-	√
<b>SNMP</b>	Simple Network Management Protocol is used in network management systems to monitor network-attached devices for conditions that warrant administrative attention	√	√
<b>RIP</b>	The Routing Information Protocol is a dynamic routing protocol used in local and wide area networks	√	√
<b>NTP</b>	The Network Time Protocol is a protocol for synchronizing the clocks of router	√	√
<b>Failover</b>	Failover	√	√
<b>Ser2net</b>	Serial to Ethernet converter	√	√
<b>Configuration</b>			
<b>WEB Application</b>	HTTP based	√	√
<b>Remote configuration</b>	Access to web interface over mobile network	√	√
<b>Configuration via serial console</b>	basic functionality	√	√
	full functionality	-	√
<b>Wizards</b>	Internet access	√	√
	GRE Tunnel	√	√
	IPSec Tunnel	-	√
<b>Default reset</b>	by external taster and configuration application	√	√
<b>File Management</b>			
<b>Upload firmware</b>	by WEB	√	√
<b>Backup configuration</b>	by WEB	√	√

Table 2 - GWR Router features

## Product Overview

### Front panel

On the front panel (*Figure 2*) the following connectors are located:

- one RJ45 connector – Ethernet port for connection into local computer network;
- one RJ45 connector for RS232 serial communication;
- reset button;
- one USB connector for connection of additional device;
- Power supply connector.

Ethernet connector LED:

- ACT (yellow) on - Network traffic detected (off when no traffic detected).
- Network Link (green LED) on - Ethernet activity or access point engaged.




Figure 2 - GWR Router front panel

The Reset button can be used for a warm reset or a reset to factory defaults.

**Warm reset:** If the GWR Router is having problem connecting to the Internet, press and hold in the Reset button for a second using the tip of a pen.

**Reset to Factory Defaults:** To restore the default settings of the GWR Router, hold the RESET button pressed for a few seconds. Restoration of the default configuration will be signaled by blinks of the first and last signal strength LED on the top panel. This will restore the factory defaults and clear all custom settings of the GWR Router. You can also reset the GWR Router to factory defaults using the Maintenance > Default Settings screen.

### Back panel

On the back panel of device (*Figure 3*) the following connectors are located:

- slot for SIM cards;
- SMA connector for connection of the GSM/UMTS antenna;




Figure 3 - GWR Router back panel

*Top Panel*

There is a sequence of 8 LED indicators on the top of this device by which the indication of the system current state, device power supply and presence of GSM/UMTS network as well as signal level is performed.



Figure 4 - GWR Router top panel side

LED Indicator Description:

1. Reset (red LED) on - the GWR Router reset state.
2. Power status (green LED) on - Power supply. Power status LED will blink when the GWR Router is in initializing state.
3. Link (red LED) will blink when connection is active.
4. Signal strength LED indicator:
  - -101 or less dBm = Unacceptable (running LED)
  - -100 to -91 dBm = Weak (1 LED)
  - -90 to -81 dBm = Moderate (2 LED)
  - -80 to -75 dBm = Good (3 LED)
  - -74 or better dBm = Excellent (4 LED)
  - 0 is not known or not detectable (running LED)

Signal strength LED will blink when GPRS/EDGE/UMTS/HSDPA connection is not active. When GPRS/EDGE connection is active Signal strength LED is on. Reset condition will be indicated by blinks of the first and last Signal strength LED. When signal quality is not known or not detectable there will be running LED indication.

## Putting Into Operation

Before putting the GWR Router in operation it is necessary to connect all components needed for the operation:

- GSM antenna;
- Ethernet cable and
- SIM card must be inserted.

And finally, device should have power supply by power supply connector and the attached adaptor.

**SIM card must not be changed, installed or taken out while device operates. This procedure is performed when power supply is not connected.**

Declaration of conformity



**RB GeneralEkonmik**  
HARDWARE · SOFTWARE · ENGINEERING



**DECLARATION OF CONFORMITY**

We hereby declare, that following product

**COMMUNICATION EQUIPMENT WIRELESS ROUTER**

Type	Product name	Technical specifications
GWR201, GWR201B, GWR202, GWR202B, GWR251, GWR251B, GWR252, GWR252B, GWR301, GWR302	GENEKO GWR ROUTER	Input: 9-12 V <sup>m</sup> , 1A

are in conformity with standards harmonised with directives:

<b>LVD</b>	EN 60950-1:2001 (1st Ed.) and/or EN 60950-1:2001
<b>EMC</b>	DIRECTIVE 2004/108/EC EN 301 489-1 V1.6.1 (2005-09) EN 301 489-7 V1.3.1 (2005-11)
<b>R&amp;TTE</b>	DIRECTIVE 1999/5/EC ETSI EN 301 511 V9.0.2 ETSI EN 301 511 V9.0.2 EN 301 908-1 & EN 301 908-2(V2.2.1)
<b>RoHS</b>	DIRECTIVE 2002/95/EC EU COMMISSION DECISION 2005/618/EC, 2005/717/EC 2005/747/EC, 2006/310/EC, 2006/690/EC 2006/691/EC and 2006/692/EC

**CE 1304**



Year of affixing of CE mark:

**2008**

Place and date:

**Belgrade, October 1, 2008**

Director

**Borisav Bojković**



**RB GeneralEkonmik**

Bul. Despota Sefana 59a • 11000 Belgrade • Serbia • tel. +381 11 3340-591, 3340-178 • fax: +381 11 3224-437 • office@geneko.co.rs • www.geneko.co.rs

Figure 5 - Declaration of conformity

## Device Configuration

There are two methods which can be used to configure the GWR Router. Administrator can use following methods to access router:

- Web browser
- Console port

Default access method is by web interface. This method gives administrator full set of privileges for configuring and monitoring. Configuration, administration and monitoring of the GWR Router can be performed through the web interface. The default IP address of the router is 192.168.1.1. Another method is by console port (RJ45 serial interface). This method has limited option for configuring the GWR Router.

### Device configuration using web application

The GWR Router's web-based utility allows you to set up the Router and perform advanced configuration and troubleshooting. This chapter will explain all of the functions in this utility.

For local access of the GWR Router's web-based utility, launch your web browser, and enter the Router's default IP address, 192.168.1.1, in the address field. A login screen prompts you for your User name and Password. Default administration credentials are admin/admin.

For administration by web interface please enter IP address of router into web browser. Please disable *Proxy server* in web browser before proceed.

geneko  
HARDWARE

GWR ROUTER - CONFIGURATION CONSOLE

Login

Username

Password

Login

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 6 - User authentication

After successfully finished process of authentication of *Username/Password* you can access *Main Configuration Menu* – which is shown at *Figure 7*.

You can set all parameters of the GWR Router using web application. All functionality and parameters are grouped through a few main tabs (windows).

## Add/Remove/Update manipulation in tables

To **Add** a new row (new rule or new parameter) in the table please do following:

- Enter data in fields at the bottom row of the table (separated with a line).
- After entering data in all fields click **Add** link.

To **Update** the row in the table:

- Change data directly in fields you want to change

To **Remove** the row from the table:

- Click **Remove** link to remove selected row from the table.

## Save/Reload changes

To save all the changes in the form press **Save** button. By clicking **Save** data are checked for validity. If they are not valid, error message will be displayed. To discard changes press the **Reload** button. By clicking **Reload**, previous settings will be loaded in the form.

## Status Information

The GWR Router's Status menu provides general information about router as well as real-time network information. Status menu has three parts:

- General Information,
- Network Information (LAN),
- WAN Information.

### Status - General

**General Information** Tab provides general information about device type, device firmware version, OS version, hardware resources utilization, MAC address of LAN port and Up Time since last reboot. Screenshot of General Router information is shown at *Figure 7*. Data in Status menu are read only and can not be changed by user. If you want to refresh screen data press **Refresh** button.

SIM Card detection is performed only at time booting the system.

The screenshot displays the 'GWR ROUTER - CONFIGURATION CONSOLE' interface. On the left is a blue sidebar menu with categories: Status, Settings, Maintenance, and Management. The main content area is titled 'Status: General' and contains a table of router specifications and a SIM card detection section.

Model	GWR252-B
Firmware Version	2.1.0_252
CPU Vendor	CirrusLogic.ARM9 EP9302 200Mh
UP Time	00:05:26
Mac Address	00:1e:5c:00:02:8d

**SIM Card Detection**

The SIM card detection section shows a graphic of a SIM card tray with two slots, SIM 1 and SIM 2. SIM 1 is highlighted with a green bar, indicating it is inserted. To the right of the graphic is a legend:

- Green square: Sim card inserted.
- Black square: Sim card not inserted.
- Yellow square: Sim card checking.
- Red square: Sim card damaged.

Below the legend, a note states: '\* SIM Card detection is performed only at time of booting the system.' A 'Refresh' button is located at the bottom right of the SIM card detection section.

Copyright © 2008 Geneko. All rights reserved.

Figure 7 - General Router information

## Status - Network Information

*Network Information* Tab provides information about Ethernet port and Ethernet traffic statistics. Screenshot of Network Router information is shown at *Figure 8*.

## Status - WAN Information

*WAN Information* Tab provides information about GPRS/EDGE/UMTS/HSDPA connection and GPRS traffic statistics. *WAN information menu* has three sub menus which provide information about:

- GPRS/EDGE/UMTS/HSDPA mobile module(manufacturer and model);
- Mobile operator and signal quality;
- Mobile traffic statistics.

Screenshot of WAN Router information is shown at *Figure 9*.

**geneko** HARDWARE

GWR ROUTER - CONFIGURATION CONSOLE

Status: Network Information

**Network Statistics**

Network Technology	Ethernet	MAC Address	00:1e:5c:00:02:8d		
IP Address	10.0.10.150	MTU Size	1500		
Netmask	255.255.255.0	Broadcast	10.0.10.255		
Data Received	174432	RX Packets	1540	RX Error Packets	0
				RX Dropped Packets	0
Data Transmitted	312877	TX Packets	567	TX Error Packets	0
				TX Dropped Packets	0
DHCP Server	stopped				

Refresh

Copyright © 2008 Geneko. All rights reserved.

Figure 8 - Network Information

Status: WAN Information

**Mobile Information**

Modem Manufacturer	SIEMENS
Modem Model	SIEMENS MC75
Modem Serial Number	355634006265786
Revision	REVISION 04.001

**Mobile Connection**

Operator	
Cell ID	04C6
Phone Number	
Signal Strength	-56dBm

**Mobile Statistics**

Protocol	Point-Point Protocol	Activity Time	00:04:40		
WAN Address	172.29.8.6	PPP Address	10.0.0.1		
Primary DNS Address	192.168.111.100	Second DNS Address	unknown		
Data Received	52	RX Packets	4	RX Error Packets	0
				RX Dropped Packets	0
Data Transmitted	101	TX Packets	6	TX Error Packets	0
				TX Dropped Packets	0

Refresh

Figure 9 - WAN Information

## Settings - Network

Click *Network* Tab, to open the LAN network screen. Use this screen to configure LAN TCP/IP settings.

Network Tab Parameters	
Label	Description
<i>Use the following IP address</i>	Choose this option if you want to manually configure TCP/IP parameters of Ethernet port.
<i>IP Address</i>	Type the IP address of your GWR Router in dotted decimal notation. 192.168.1.1 is the factory default IP address.
<i>Subnet Mask</i>	The subnet mask specifies the network number portion of an IP address. The GWR Router support sub-netting. You must specified subnet mask for your LAN TCP/IP settings.
<i>Local DNS</i>	Type the IP address of your local DNS server.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router. Whether you make changes or not, router will reboot every time you click <i>Save</i> .

Table 3 - Network parameters

At the *Figure 10* you can see screenshot of *Network* Tab configuration menu.



Figure 10 - Network parameters configuration page

## Settings - DHCP Server

The GWR Router can be used as a DHCP (Dynamic Host Configuration Protocol) server on your network. A DHCP server automatically assigns available IP addresses to computer on your network. If you choose to enable the DHCP server option, all of the computers on your LAN must be set to obtain an IP address automatically from a DHCP server. (By default, Windows computers are set to obtain an IP automatically.)

To use the GWR Router as your network's DHCP server, click **DHCP Server** Tab for DHCP Server setup. The GWR Router has built-in DHCP server capability that assigns IP addresses and DNS servers to systems that support DHCP client capability.

DHCP Server Parameters	
Label	Description
<b>Enable DHCP Server</b>	DHCP (Dynamic Host Configuration Protocol) allows individual clients (workstations) to obtain TCP/IP configuration at startup from a server. When configured as a server, the GWR Router provides TCP/IP configuration for the clients. To activate DHCP server, click check box <b>Enable DHCP Server</b> . To setup DHCP server fill in the IP Starting Address and IP Ending Address fields. Uncheck <b>Enable DHCP Server</b> check box to stop the GWR Router from acting as a DHCP server. When Unchecked, you must have another DHCP server on your LAN, or else the computers must be manually configured.
<b>IP Starting Address</b>	This field specifies the first of the contiguous addresses in the IP address pool.
<b>IP Ending Address</b>	This field specifies last of the contiguous addresses in the IP address pool.
<b>Lease Duration</b>	This field specifies DHCP session duration time.
<b>Primary DNS, Secondary DNS</b>	This field specifies IP addresses of DNS server that will be assigns to systems that support DHCP client capability. Select <b>None</b> to stop the DHCP Server from assigning DNS server IP address. When you select None, computers must be manually configured with proper DNS IP address. Select <b>Used by ISP</b> to have the GWR Router assigns DNS IP address to DHCP clients. DNS address is provided by ISP (automatically obtained from WAN side). This option is available only if GPRS connection is active. Please establish GPRS connection first and then choose this option. Select <b>Used Defined</b> to have the GWR Router assigns DNS IP address to DHCP clients. DNS address is manually configured by user.
<b>Static Lease Reservation</b>	This field specifies IP addresses that will be dedicated to specific DHCP Client based on MAC address. DHCP server will always assign same IP address to appropriate client.
<b>Address Exclusions</b>	This field specifies IP addresses that will be excluded from the pool of DHCP IP address. DHCP server will not assign this IP to DHCP clients.
<b>Add</b>	Click <b>Add</b> to insert (add) new item in table to the GWR Router.
<b>Remove</b>	Click <b>Remove</b> to delete selected item from table.
<b>Save</b>	Click <b>Save</b> to save your changes back to the GWR Router.
<b>Reload</b>	Click <b>Reload</b> to discard any changes and reload previous settings.

Table 4 - DHCP Server parameters

**geneko** HARDWARE  
GWR ROUTER - CONFIGURATION CONSOLE

**Status**  
General  
Network Information  
WAN Information

**Settings**  
Network  
DHCP Server  
WAN Settings  
Routing  
Dynamic Routing Protocol  
RIP  
VPN Settings  
GRE  
IP Filtering

**Maintenance**  
Administrator Password  
Device Identity Settings  
Date/Time Settings  
Diagnostics  
Update Firmware  
Settings Backup  
Reboot  
Default Settings

**Management**  
Serial Port  
SNMP  
Logs  
Logout

### DHCP Server

Enable Dynamic Host Configuration Protocol (DHCP) Server

IP Address range: From  To

Lease Duration:  days  hrs  mins

Primary DNS:  None  Used by ISP  User Defined

Secondary DNS:  None  Used by ISP  User Defined

**Static Lease Reservations:**

Enable	IP Address	Mac Address	Action
<input type="checkbox"/>			<a href="#">Add</a>

**Address Exclusions:**

Enable	Start Address	End Address	Action
<input checked="" type="checkbox"/>	10.0.10.152	10.0.10.153	<a href="#">Rem</a>
<input type="checkbox"/>			<a href="#">Add</a>

\* Mac Address format: xx:xx:xx:xx:xx:xx  
\* The IP address pool must specify addresses that are in the subnetwork of the GWR Router. The DHCP server will not operate if this configuration does not meet this requirement.  
\* A reservation IP address must not be the same as the IP address of the DHCP server itself. It must be a valid IP address in the subnetwork of the DHCP server. The DHCP server will ignore a reservation that does not meet these requirements.  
\* An IP address exclusion range must specify valid IP addresses in the subnetwork of the DHCP server. The DHCP server will ignore an exclusion that does not meet this requirement.

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 11 - DHCP Server configuration page

## Settings - WAN Setting

Click *WAN Settings* Tab, to open the Wireless screen. Use this screen to configure the GWR Router GPRS/EDGE/UMTS/HSDPA parameters (Figure 12).

The screenshot displays the WAN Settings configuration page. On the left is a navigation menu with categories like Status, Settings, Maintenance, and Management. The main area is titled 'WAN Settings' and is divided into two sections: SIM 1 and SIM 2. SIM 1 is enabled and configured with Provider 'telenor', Authentication 'PAP', Username 'geneko', Password 'geneko', Dial string 'ATD\*99\*\*\*1#', Initial string 'at+cgdcont=1,"IP","geneko"', and Number of retry '1'. SIM 2 is disabled. Below these sections are 'Reload' and 'Save' buttons. A 'Wireless Module Status' table shows 'SIEMENS MC75' with 'EDGE Attached' communication and 'ppp0' port. The connection status is 'Connected'. At the bottom, there are 'Refresh' and 'Disconnect' buttons and a copyright notice for Geneko.

Figure 12 - WAN Settings configuration page

WAN Settings	
Label	Description
<i>Provider</i>	This field specifies name of GSM/UMTS ISP. You can setup any name for provider.
<i>Authentication</i>	This field specifies password authentication protocol. From the pop up window choose appropriate protocol (PAP, CHAP, PAP - CHAP).
<i>Username</i>	This field specifies Username for client authentication at GSM/UMTS network. Mobile provider will assign you specific username for each SIM card.
<i>Password</i>	This field specifies Password for client authentication at GSM/UMTS network. Mobile provider will assign you specific password for each SIM card.
<i>Dial String</i>	This field specifies Dial String for GSM/UMTS modem connection initialization. In most cases you have to change only APN field based on parameters obtained from Mobile Provider.
<i>Initial String</i>	This field specifies Initial String for GSM/UMTS modem initialization. In most cases you can leave this field at default values.
<i>Enable Failover</i>	Mark this option in order to enable failover feature. This feature is used when both SIM have been enabled. You specify the amount of time after which Failover feature brings down current WAN connection (SIM2) and brings up previous WAN connection (SIM1).
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.

<i>Save</i>	Click <i>Save</i> to save your changes back to the GWR Router.
<i>Refresh</i>	Click <i>Refresh</i> to see updated mobile network status.
<i>Connect/Disconnect</i>	Click <i>Connect/Disconnect</i> to connect or disconnect from mobile network.

Table 5 - WAN parameters

Figure 12 shows screenshot of GSM/UMTS tab configuration menu. GSM/UMTS menu is divided into two parts.

- Upper part provides all parameters for configuration GSM/UMTS connection. These parameters can be obtained from Mobile Operator. Please use exact parameters given from Mobile Operator.
- Bottom part is used for monitoring status of GSM/UMTS connection (create/maintain/destroy GSM/UMTS connection). Status line show real-time status: connected/disconnected.

If your SIM Card credit is too low, the GWR Router will performed periodically connect/disconnect actions.

WAN Settings(advanced)	
Label	Description
<i>Enable</i>	This field specifies if Advanced WAN settings is enables at the GWR Router.
<i>Accept Local IP Address</i>	With this option, pppd will accept the peer's idea of our local IP address, even if the local IP address was specified in an option.
<i>Accept Remote IP Address</i>	With this option, pppd will accept the peer's idea of its (remote) IP address, even if the remote IP address was specified in an option.
<i>Idle time before disconnect sec</i>	Specifies that pppd should disconnect if the link is idle for <i>n</i> seconds. The link is idle when no data packets are being sent or received.
<i>Refuse PAP</i>	With this option, pppd will not agree to authenticate itself to the peer using PAP.
<i>Require PAP</i>	Require the peer to authenticate using PAP (Password Authentication Protocol) authentication.
<i>Refuse CHAP</i>	With this option, pppd will not agree to authenticate itself to the peer using CHAP.
<i>Require CHAP</i>	Require the peer to authenticate using CHAP (Challenge Handshake Authentication Protocol) authentication.
<i>Max. CHAP challenge transmissions</i>	Set the maximum number of CHAP challenge transmissions to <i>n</i> (default 10).
<i>CHAP restart interval sec</i>	Set the CHAP restart interval (retransmission timeout for challenges) to <i>n</i> seconds (default 3).
<i>Refuse MS-CHAP</i>	With this option, pppd will not agree to authenticate itself to the peer using MS-CHAP.
<i>Refuse MS-CHAPv2</i>	With this option, pppd will not agree to authenticate itself to the peer using MS-CHAPv2.
<i>Refuse EAP</i>	With this option, pppd will not agree to authenticate itself to the peer using EAP.
<i>Connection debugging</i>	Enables connection debugging facilities. If this option is given, pppd will log the contents of all control packets sent or received in a readable form.
<i>Maximum Transmit Unit bytes</i>	Set the MTU (Maximum Transmit Unit) value to <i>n</i> . Unless the peer requests a smaller value via MRU negotiation, pppd will request that the kernel networking

	code send data packets of no more than $n$ bytes through the PPP network interface.
<b>Maximum Receive Unit bytes</b>	Set the MRU (Maximum Receive Unit) value to $n$ . Pppd will ask the peer to send packets of no more than $n$ bytes. The value of $n$ must be between 128 and 16384; the default is 1500.
<b>VJ-Compression</b>	Disable Van Jacobson style TCP/IP header compression in both directions.
<b>VJ-Connection-ID Compression</b>	Disable the connection-ID compression option in Van Jacobson style TCP/IP header compression. With this option, pppd will not omit the connection-ID byte from Van Jacobson compressed TCP/IP headers.
<b>Protocol Field Compression</b>	Disable protocol field compression negotiation in both directions.
<b>Address/Control Compression</b>	Disable Address/Control compression in both directions.
<b>Predictor-1 Compression</b>	Disable or enable accept or agree to Predictor-1 compression.
<b>BSD Compression</b>	Disable or enable BSD-Compress compression.
<b>Deflate Compression</b>	Disable or enable Deflate compression.
<b>Compression Control Protocol negotiation</b>	Disable CCP (Compression Control Protocol) negotiation. This option should only be required if the peer is buggy and gets confused by requests from pppd for CCP negotiation.
<b>Magic Number negotiation</b>	Disable magic number negotiation. With this option, pppd cannot detect a looped-back line. This option should only be needed if the peer is buggy.
<b>Passive Mode</b>	Enables the "passive" option in the LCP. With this option, pppd will attempt to initiate a connection; if no reply is received from the peer, pppd will then just wait passively for a valid LCP packet from the peer, instead of exiting, as it would without this option.
<b>Silent Mode</b>	With this option, pppd will not transmit LCP packets to initiate a connection until a valid LCP packet is received from the peer (as for the "passive" option with ancient versions of pppd).
<b>Append domain name</b>	Append the domain name $d$ to the local host name for authentication purposes.
<b>Show PAP password in log</b>	When logging the contents of PAP packets, this option causes pppd to show the password string in the log message.
<b>Time to wait before re-initiating the link sec</b>	Specifies how many seconds to wait before re-initiating the link after it terminates. The holdoff period is not applied if the link was terminated because it was idle.
<b>LCP-Echo-Failure</b>	If this option is given, pppd will presume the peer to be dead if $n$ LCP echo-requests are sent without receiving a valid LCP echo-reply. If this happens, pppd will terminate the connection. This option can be used to enable pppd to terminate after the physical connection has been broken (e.g., the modem has hung up) in situations where no hardware modem control lines are available.
<b>LCP-Echo-Interval</b>	If this option is given, pppd will send an LCP echo-request frame to the peer every $n$ seconds. Normally the peer should respond to the echo-request by sending an echo-reply. This option can be used with the <i>lcp-echo-failure</i> option to detect that the peer is no longer connected.
<b>Add a default route</b>	Add a default route to the system routing tables, using the peer as the gateway, when IPCP negotiation is successfully completed. This entry is removed when the PPP connection is broken.

Table 6 - Advanced WAN Settings

## Settings - Routing

The static routing function determines the path that data follows over your network before and after it passes through the GWR Router. You can use static routing to allow different IP domain users to access the Internet through the GWR Router. Static routing is a powerful feature that should be used by advanced users only. In many cases, it is better to use dynamic routing because it enables the GWR Router to automatically adjust to physical changes in the network's layout.

The GWR Router is a full functional router with static routing capability. *Figure 13* show screenshot of Routing Menu.

The screenshot displays the 'Routing' configuration page in the GWR Router Configuration Console. The interface includes a sidebar menu on the left with options like 'General', 'Network Information', 'WAN Information', 'Settings', 'Network', 'DHCP Server', 'WAN Settings', 'Routing', 'Dynamic Routing Protocol', 'RIP', 'VPN Settings', 'GRE', 'IP Filtering', 'Maintenance', 'Management', and 'Logout'. The main content area is titled 'Routing' and contains the following sections:

- Routing table (Local network):** A table with columns: Enable, Dest Network, Netmask, Gateway, Metric, Interface. It shows two entries: 10.0.0.1 with netmask 255.255.255.255 and interface ppp0; and 10.0.10.0 with netmask 255.255.255.0 and interface eth0.
- Routing table:** A table with columns: Enable, Dest Network, Netmask, Gateway, Metric, Interface, Action. It shows two entries: 0.0.0.0 with metric 1 and interface ppp0 (Action: Rem); and 192.168.1.0 with netmask 255.255.255.0 and interface gre1 (Action: Rem). There is also an empty row with interface eth0 and Action Add.
- Forward protocol connections from external networks to the following internal devices:** A table with columns: Enable, Tunneling Protocol, Send to. It shows GRE (Send to: 10.0.0.1) and ESP (Send to: 10.0.0.2).
- Forward TCP/UDP connections from external networks to the following internal devices:** A table with columns: Enable, Protocol, Source Port, Dest IP Address, Destination Port, Action. It shows a row for TCP with an empty Source Port field and an Action Add button.

At the bottom right of the configuration area are 'Reload' and 'Save' buttons. At the bottom center, there is a copyright notice: 'Copyright © 2008 Geneko. All rights reserved. http://www.geneko.co.rs/'.

Figure 13 - Routing configuration page

Use this menu to setup all routing parameters. Administrator can perform following operations:

- Create/Edit/Remove routes (including default route),
- Reroute GRE and IPSEC packet to dedicated destination at inside network
- Port translation - Reroute TCP and UPD packets to desire destination at inside network.

Routing Settings	
Label	Description
<i>Routing Table</i>	
<b>Enable</b>	This check box allows you to activate/deactivate this static route.
<b>Dest Network</b>	This parameter specifies the IP network address of the final destination. Routing is always based on network number. If you need to specify a route to a single host, use a subnet mask of 255.255.255.255 in the subnet mask field to force the network number to be identical to the host ID.
<b>Netmask</b>	This parameter specifies the IP netmask address of the final destination.

<b>Gateway</b>	This is the IP address of the gateway. The gateway is a router or switch (next hop) on the same network segment as the device's LAN or WAN port. The gateway helps forward packets to their final destinations. For every routing rule enter the IP address of the gateway. Please notice that <i>ppp0</i> interface has only one default gateway (provided by Mobile operator) and because of that that there is no option for gateway when you choose <i>ppp0</i> interface.
<b>Metric</b>	Metric represents the "cost" of transmission for routing purposes. IP routing uses hop count as the measurement of cost, with a minimum of 1 for directly connected networks. Enter a number that approximates the cost for this link. The number need not be precise, but it must be between 1 and 15. In practice, 2 or 3 is usually a good number.
<b>Interface</b>	Interface represents the "exit" of transmission for routing purposes. In this case <i>Eth0</i> represent LAN interface an <i>ppp0</i> represent GSM/UMTS mobile interface of the GWR Router.
<b>VPN Traffic redirection</b>	
<b>Enable</b>	This check box allows you to activate/deactivate this static Protocol translation.
<b>ESP</b>	Encapsulated Security Payload (ESP) protects the IP packet data from third party interference, by encrypting the contents using symmetric cryptography algorithms. Unlike AH, the IP packet header is not protected by ESP. ESP operates directly on top of IP, using IP protocol number 50.
<b>GRE</b>	Generic Routing Encapsulation (GRE) is a tunneling protocol designed to encapsulate a wide variety of network layer packets inside IP tunneling packets. The original packet is the payload for the final packet. GRE creates a virtual point-to-point link with routers at remote points on an IP Internet work. GRE uses IP protocol number 47.
<b>Sent to</b>	This field specifies IP address of the VPN server on local area network. VPN tunnel ends at this VPN server. You must use VPN tunnel option when configuring VPN connection, because of NAT.
<b>TCP/UDP Traffic redirection</b>	
<b>Enable</b>	This check box allows you to activate/deactivate this static port translation.
<b>Protocol</b>	This is the IP protocol type.
<b>Source Port</b>	This is the TCP/UDP port of incoming traffic.
<b>Dest IP address</b>	This field specifies IP address of the Virtual server (Computer on the LAN where traffic is redirected).
<b>Destination Port</b>	This is the TCP/UDP port of application.
<b>Add</b>	Click <b>Add</b> to insert (add) new item in table to the GWR Router.
<b>Remove</b>	Click Remove to delete selected item from table.
<b>Reload</b>	Click <b>Reload</b> to discard any changes and reload previous settings.
<b>Save</b>	Click <b>Save</b> to save your changes back to the GWR Router. After pressing <b>Save button</b> it make take more then 10 seconds for router to save parameters and become operational again.

Table 7 - Routing parameters

Port translation

For incoming data, the GWR Router forwards IP traffic destined for a specific port, port range or GRE/IPsec protocol from the cellular interface to a private IP address on the Ethernet "side" of the GWR Router.

Settings – Dynamic Routing Protocol

Dynamic routing performs the same function as static routing except it is more robust. Static routing allows routing tables in specific routers to be set up in a static manner so network routes for packets are set. If a router on the route goes down the destination may become unreachable. Dynamic routing allows routing tables in routers to change as the possible routes change.

Routing Information Protocol (RIP)

The Routing Information Protocol (RIP) is a dynamic routing protocol used in local and wide area networks. As such it is classified as an interior gateway protocol (IGP) using the distance-vector routing algorithm. The Routing Information Protocol provides great network stability, guaranteeing that if one network connection goes down the network can quickly adapt to send packets through another connection.

Click *RIP* Tab, to open the Routing Information Protocol screen. Use this screen to configure the GWR Router RIP parameters (Figure 14).




Figure 14 - RIP configuration page

RIP Settings	
Label	Description
<i>Routing Manager</i>	
<i>Hostname</i>	Prompt name that will be displayed on telnet console.
<i>Password</i>	Login password.
<i>Enable log</i>	Enable log file.
<i>Port to bind at</i>	Local port the service will listen to.
<i>RIPD</i>	
<i>Hostname</i>	Prompt name that will be displayed on telnet console of the Routing Information Protocol Manager.
<i>Password</i>	Login password.
<i>Port to bind at</i>	Local port the service will listen to.
<i>Routing Information Protocol Status</i>	
<i>Start</i>	Start RIP.
<i>Stop</i>	Stop RIP.
<i>Restart</i>	Restart RIP.
<i>Save</i>	Click <i>Save</i> to save your changes back to the GWR Router.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.

Table 8 - RIP parameters

### RIP routing engine for the GWR Router

Use telnet to enter in global configuration mode.

```
telnet 192.168.1.1 2602 // telnet to eth0 at TCP port 2602//
```

To enable RIP, use the following commands beginning in global configuration mode:

```
router# router rip
```

To associates a network with a RIP routing process, use following commans:

```
router# network [A.B.C.D/Mask]
```

By default, the GWR Router receives RIP version 1 and version 2 packets. You can configure the GWR Router to receive an send only version 1. Alternatively, tou can configure the GWR Router to receive and send only version 2 packets. To configure GWR Router to send and receive packets from only one version, use the following command:

```
router# rip version [1|2] // Same as other router //
```

Disable route redistribution:

```
router# no redistribute kernel
router# no redistribute static
router# no redistribute connected
```

Disable RIP update (optional):

```
router# passive-interface eth0  
router# no passive-interface eth0
```

Routing protocols use several timer that determine such variables as the frequency of routing updates, the length of time before a route becomes invalid, an other parameters. You can adjust these timer to tune routing protocol performance to better suit your internetwork needs. Use following command to setup RIP timer:

```
router# timers basic [UPDATE-INTERVAL] [INVALID] [TIMEOUT] [GARBAGE-COLLECT]  
router# no timers basic
```

Configure interface for RIP protocol

```
router# interface greX  
router# ip rip send version [VERSION]  
router# ip rip receive version [VERSION]
```

Disable rip authentication at all interface.

```
router(interface)# no ip rip authentication mode [md5|text]
```

Debug commands:

```
router# debug rip  
router# debug rip events  
router# debug rip packet  
router# terminal monitor
```

## Settings - VPN Settings

Virtual private network (VPN) is a communications network tunneled through another network, and dedicated for a specific network. One common application is secure communications through the public Internet, but a VPN need not have explicit security features, such as authentication or content encryption. VPNs, for example, can be used to separate the traffic of different user communities over an underlying network with strong security features.

A VPN may have best-effort performance, or may have a defined Service Level Agreement (SLA) between the VPN customer and the VPN service provider. Generally, a VPN has a topology more complex than point-to-point. The distinguishing characteristics of VPNs are not security or performance, but that they overlay other network(s) to provide a certain functionality that is meaningful to a user community.

### Generic Routing Encapsulation (GRE)

Originally developed by Cisco, generic routing encapsulation (GRE) is now a standard, defined in RFC 1701, RFC 1702, and RFC 2784. GRE is a tunneling protocol used to transport packets from one network through another network.

If this sounds like a virtual private network (VPN) to you, that's because it theoretically is: Technically, a GRE tunnel is a type of a VPN – but it isn't a secure tunneling method. However, you can encrypt GRE with an encryption protocol such as IPSec to form a secure VPN. In fact, the point-to-point tunneling protocol (PPTP) actually uses GRE to create VPN tunnels. For example, if you configure Microsoft VPN tunnels, by default, you use PPTP, which uses GRE.

Solution where you can use GRE protocol:

- You need to encrypt multicast traffic. GRE tunnels can carry multicast packets – just like real network interfaces – as opposed to using IPSec by itself, which can't encrypt multicast traffic. Some examples of multicast traffic are OSPF, EIGRP. Also, a number of video, VoIP, and streaming music applications use multicast.
- You have a protocol that isn't routable, such as NetBIOS or non-IP traffic over an IP network. You could use GRE to tunnel IPX/AppleTalk through an IP network.
- You need to connect two similar networks connected by a different network with different IP addressing.

Click **VPN Settings** Tab, to open the VPN configuration screen. At the *Figure 15* you can see screenshot of **GRE** Tab configuration menu.

VPN Settings / GRE Tunneling Parameters	
Label	Description
<b>Enable</b>	This check box allows you to activate/deactivate VPN/GRE traffic.
<b>Local Tunnel Address</b>	This field specifies IP address of virtual tunnel interface.
<b>Local Tunnel Netmask</b>	This field specifies the IP netmask address of virtual tunnel. This field is unchangeable, always 255.255.255.252
<b>Tunnel Source</b>	This field specifies IP address of tunnel source.
<b>Tunnel Destination</b>	This field specifies IP address of tunnel destination.
<b>Interface</b>	This field specifies GRE interface. This field gets from the GWR Router.
<b>KeepAlive Enable</b>	Check for keepalive enable.
<b>Period</b>	Defines the time interval (in seconds) between transmitted keepalive packets. Enter a number from 3 to 60 seconds.
<b>Retries</b>	Defines the number of times retry after failed keepalives before determining that the tunnel endpoint is down. Enter a number from 1 to 10 times.

<b>Add</b>	Click <b>Add</b> to insert (add) new item in table to the GWR Router.
<b>Remove</b>	Click <b>Remove</b> to delete selected item from table.
<b>Reload</b>	Click <b>Reload</b> to discard any changes and reload previous settings.
<b>Save</b>	Click <b>Save</b> to save your changes back to the GWR Router.

Table 9 - GRE parameters

**VPN Settings - GRE**

**Generic Routing Encapsulation (GRE) Tunneling**

Enable	Local Tunnel Address	Local Tunnel Netmask	Tunnel Source	Tunnel Destination	Interface	KeepAlive Enable	Period	Retries	Action
<input checked="" type="checkbox"/>	10.10.10.2	255.255.255.252	172.27.76.82	172.27.76.80	gre1	<input type="checkbox"/>			Rem
<input type="checkbox"/>						<input type="checkbox"/>			Add

Local Tunnel Address: IP Address of virtual tunnel interface  
 Local Tunnel Netmask: (Unchangeable, always 255.255.255.252)  
 Tunnel Source: IP address of tunnel source  
 Tunnel Destination: IP address of tunnel destination  
 Period: Valid values [3-60]  
 Retries: Valid values [1-10]

Reload Save

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 15 - GRE tunnel parameters configuration page

**GRE Keepalive**

GRE tunnels can use periodic status messages, known as keepalives, to verify the integrity of the tunnel from end to end. By default, GRE tunnel keepalives are disabled. Use the keepalive check box to enable this feature. Keepalives do not have to be configured on both ends of the tunnel in order to work; a tunnel is not aware of incoming keepalive packets. You should to define the time interval (in seconds) between transmitted keepalive packets. Enter a number from 1 to 60 seconds, and the number of times to retry after failed keepalives before determining that the tunnel endpoint is down. Enter a number from 1 to 10 times.

Internet Protocol Security (IPSec)

Internet Protocol Security (IPSec) is a protocol suite for securing Internet Protocol communication by authenticating and encrypting each IP packet of a data stream.

Click **VPN Settings** Tab, to open the VPN configuration screen. At the *Figure 16* you can see IPSec Summary screen. This screen gathers information about settings of all defined IPSec tunnels. You can define up to 5 Device-to-Device tunnels.




Figure 16 - IPSec Summary screen

VPN Settings / IPSec Summary	
Label	Description
<b>Tunnels Used</b>	This is the number of IPSec tunnels being defined.
<b>Tunnels Available</b>	This is the number of available, not yet defined, IPSec tunnels.
<b>No</b>	This field indicates the number of the IPSec tunnel.
<b>Name</b>	Field shows the Tunnel Name that you gave to the IPSec tunnel.
<b>Enable</b>	This field shows if tunnel is enabled or disabled. After clicking on <b>Start</b> button, only enabled tunnels will be started.
<b>Status</b>	Field indicates status of the IPSec tunnel. Click on <b>Refresh</b> button to see current status of defined IPSec tunnels.
<b>Enc/Auth/Grp</b>	This field shows both Phase 1 and Phase 2 details, Encryption method (DES/3DES/AES), Authentication method (MD5/SHA1), and DH Group number (1/2/5) that you have defined in the IPSec Setup section.
<b>Advanced Setup</b>	Field shows the chosen options from IPSec Advanced section by displaying the first letters of enabled options.
<b>Local Group</b>	Field shows the IP address and subnet mask of the Local Group.
<b>Remote Group</b>	Field displays the IP address and subnet mask of the Remote Group.
<b>Remote Gateway</b>	Field shows the IP address of the Remote Device.

<b>Delete</b>	Click on this link to delete the tunnel and all settings for that particular tunnel.
<b>Edit</b>	This link opens screen where you can change the tunnel's settings.
<b>Add New Tunnel</b>	Click on this button to add a new Device-to-Device IPSec tunnel. After you have added the tunnel, you will see it listed in the Summary table.
<b>Start</b>	This button starts the IPSec negotiations between all defined and enabled tunnels. If the IPSec is already started, Start button is replaced with Restart button.
<b>Stop</b>	This button will stop all IPSec started negotiations.
<b>Refresh</b>	Click on this button to refresh the Status field in the Summary table.

Table 10 - IPSec Summary

To create a tunnel click Add New Tunnel button. Depending on your selection, the Local Group Setup and Remote Group Setup settings will differ. Proceed to the appropriate instructions for your selection.

**Add New Tunnel**

Tunnel Number

Tunnel Name

Enable

---

**Local Group Setup**

Local Security Gateway Type

IP Address

Local Security Group Type

IP Address

---

**Remote Group Setup**

Remote Security Gateway Type

IP Address

Remote Security Group Type

IP Address

Figure 17 - IPSec Settings part I

IPSec Setup	
Keying Mode	IKE with Preshared key
Phase 1 DH Group	Group1
Phase 1 Encryption	DES
Phase 1 Authentication	MD5
Phase 1 SA Life Time	28800 seconds
Perfect Forward Secrecy	<input type="checkbox"/>
Phase 2 Encryption	DES
Phase 2 Authentication	MD5
Phase 2 SA Life Time	3600 seconds
Preshared Key	<input type="text"/>
Advanced	
<input type="checkbox"/> Aggressive Mode	
<input type="checkbox"/> Compress (Support IP Payload Compression Protocol (IPComp))	
<input type="checkbox"/> Dead Peer Deection (DPD)	20 sec
<input type="checkbox"/> NAT Traversal	

Figure 18 - IPSec Settings part II

VPN Settings / IPSec Settings	
Label	Description
<b>Tunnel Number</b>	This number will be generated automatically and it represents the tunnel number.
<b>Tunnel Name</b>	Enter a name for the IPSec tunnel. This allows you to identify multiple tunnels and does not have to match the name used at the other end of the tunnel.
<b>Enable</b>	Check this box to enable the IPSec tunnel.
<b>Local Security Gateway Type</b>	Select the type you want to use: IP Only - Only a specific IP address will be able to establish a tunnel. <i>NOTE: The Local Security Gateway Type you select should match the Remote Security Gateway Type selected on the IPSec device at the other end of the tunnel</i>
<b>IP Address</b>	The WAN (or Internet) IP address of the Router automatically appears. If the Router is not yet connected to the GSM/UMTS network this field is without IP address.
<b>Local Security Group Type</b>	Select the local LAN user(s) behind the Router that can use this IPSec tunnel. Select the type you want to use: IP or Subnet. <i>NOTE: The Local Security Group Type you select should match the Remote Security Group Type selected on the IPSec device at the other end of the tunnel.</i>
<b>IP Address</b>	Only the computer with a specific IP address will be able to access the tunnel.
<b>Subnet Mask</b>	Enter the subnet mask.
<b>Remote Security Gateway Type</b>	Select the remote LAN user(s) behind the Router at the other end that can use this IPSec tunnel. Select the type you want to use: IP or Subnet. <i>NOTE: The Remote Security Group Type you select should match the Local Security Group Type selected on the IPSec device at the other end of the tunnel.</i>
<b>IP Address</b>	Only the computer with a specific IP address will be able to access the tunnel.
<b>Remote Security Group Type</b>	Select the remote LAN user(s) behind the Router at the other end that can use this IPSec tunnel. Select the type you want to use: IP or Subnet. <i>NOTE: The Remote Security Group Type you select should match the Local Security Group Type selected on the IPSec device at the other end of the tunnel.</i>

<b>IP Address</b>	Only the computer with a specific IP address will be able to access the tunnel.
<b>Subnet Mask</b>	Enter the subnet mask.
<b>IPSec Setup</b>	In order to establish an encrypted tunnel, the two ends of an IPSec tunnel must agree on the methods of encryption, decryption and authentication. This is done by sharing a key to the encryption code. For key management, the Router uses only IKE with Preshared Key mode.
<b>Keying Mode</b>	<b>IKE with Preshared Key</b> IKE is an Internet Key Exchange protocol used to negotiate key material for Security Association (SA). IKE uses the Preshared Key to authenticate the remote IKE peer. Both ends of IPSec tunnel must use the same mode of key management.
<b>Phase 1 DH Group</b>	Phase 1 is used to create the SA. DH (Diffie-Hellman) is a key exchange protocol used during Phase 1 of the authentication process to establish pre-shared keys. There are three groups of different prime key lengths. Group 1 is 768 bits, Group 2 is 1024 bits and Group 5 is 1536 bits long. If network speed is preferred, select Group 1. If network security is preferred, select Group 5.
<b>Phase 1 Encryption</b>	Select a method of encryption: DES (56-bit), 3DES (168-bit) or AES-128 (128-bit). The method determines the length of the key used to encrypt or decrypt ESP packets. AES-128 is recommended because it is the most secure. Make sure both ends of the IPSec tunnel use the same encryption method.
<b>Phase 1 Authentication</b>	Select a method of authentication: MD5 or SHA1. The authentication method determines how the ESP packets are validated. MD5 is a one-way hashing algorithm that produces a 128-bit digest. SHA1 is a one-way hashing algorithm that produces a 160-bit digest. SHA1 is recommended because it is more secure. Make sure both ends of the IPSec tunnel use the same authentication method.
<b>Phase 1 SA Life Time</b>	Configure the length of time IPSec tunnel is active in Phase 1. The default value is 28800 seconds. Both ends of the IPSec tunnel must use the same Phase 1 SA Life Time setting.
<b>Perfect Forward Secrecy</b>	If the Perfect Forward Secrecy (PFS) feature is enabled, IKE Phase 2 negotiation will generate new key material for IP traffic encryption and authentication, so hackers using brute force to break encryption keys will not be able to obtain future IPSec keys. Both ends of the IPSec tunnel must enable this option in order to use the function.
<b>Phase 2 DH Group</b>	If the Perfect Forward Secrecy feature is disabled, then no new keys will be generated, so you do not need to set the Phase 2 DH Group. There are three groups of different prime key lengths. Group 1 is 768 bits, Group 2 is 1024 bits, and Group 5 is 1536 bits long. If network speed is preferred, select Group 1. If network security is preferred, select Group 5. You do not have to use the same DH Group that you used for Phase 1, but both ends of the IPSec tunnel must use the same Phase 2 DH Group.
<b>Phase 2 Encryption</b>	Phase 2 is used to create one or more IPSec SAs, which are then used to key IPSec sessions. Select a method of encryption: NULL, DES (56-bit), 3DES (168-bit) or AES-128 (128-bit). It determines the length of the key used to encrypt or decrypt ESP packets. AES-128 is recommended because it is the most secure. Both ends of the IPSec tunnel must use the same Phase 2 Encryption setting. <i>NOTE: If you select a NULL method of encryption, the next Phase 2 Authentication method cannot be NULL and vice versa.</i>
<b>Phase 2 Authentication</b>	Select a method of authentication: NULL, MD5 or SHA1. The authentication method determines how the ESP packets are validated. MD5 is a one-way hashing algorithm that produces a 128-bit digest. SHA1 is a one-way hashing algorithm that produces a 160-bit digest. SHA1 is recommended because it is more secure. Both ends of the IPSec tunnel must use the same Phase 2

	Authentication setting. <i>NOTE: If you select a NULL method of authentication, the previous Phase 2 Encryption method cannot be NULL.</i>
<b>Phase 2 SA Life Time</b>	Configure the length of time an IPSec tunnel is active in Phase 2. The default is 3600 seconds. Both ends of the IPSec tunnel must use the same Phase 2 SA Life Time setting.
<b>Preshared Key</b>	This specifies the pre-shared key used to authenticate the remote IKE peer. Enter a key of keyboard and hexadecimal characters, e.g., Ay_%4222 or 345fa929b8c3e. This field allows a maximum of 1023 characters and/or hexadecimal values. Both ends of the IPSec tunnel must use the same Preshared Key. <i>NOTE: It is strongly recommended that you periodically change the Preshared Key to maximize security of the IPSec tunnels.</i>
<b>Aggressive Mode</b>	There are two types of Phase 1 exchanges, Main Mode and Aggressive Mode. Aggressive Mode requires half of the main mode messages to be exchanged in Phase 1 of the SA exchange. If network security is preferred, don't use this option (Main Mode will be used). If network speed is preferred, select Aggressive Mode. Both ends of the IPSec tunnel must use the same mode of exchanges. <i>NOTE: If the GWR Router is at both ends, it is sufficient to enable Aggressive mode only at one end and the other end will automatically detect that Aggressive mode is proposed and switch to this mode.</i>
<b>Compress (IP Payload Compression Protocol (IP Comp))</b>	IP Payload Compression is a protocol that reduces the size of IP datagram. Select this option if you want the Router to propose compression when it initiates a connection.
<b>Dead Peer Detection (DPD)</b>	When DPD is enabled, the Router will send periodic HELLO/ACK messages to check the status of the IPSec tunnel (this feature can be used only when both peers or IPSec devices of the IPSec tunnel use the DPD mechanism). Once a dead peer has been detected, the Router will disconnect the tunnel so the connection can be re-established. Specify the interval between HELLO/ACK messages (how often you want the messages to be sent). The default interval is 20 seconds.
<b>NAT Traversal</b>	Both the IPSec initiator and responder must support the mechanism for detecting the NAT router in the path and changing to a new port, as defined in RFC 3947. <i>NOTE: If you select this mode the Aggressive mode will be automatically selected because it is obligatory option for NAT-T to work properly.</i> <i>NOTE: Keep-alive for NAT-T function is enabled by default and cannot be disabled. The default interval for keep-alive packets is 20 seconds.</i>
<b>Back</b>	Click <b>Back</b> to return on IPSec Summary screen.
<b>Reload</b>	Click <b>Reload</b> to discard any changes and reload previous settings.
<b>Save</b>	Click <b>Save</b> to save your changes back to the GWR Router. After that router automatically goes back and begin negotiations of the tunnels by clicking on the Start button.

Table 11 - IPSec Parameters

## Settings - IP Filtering

IP filtering is simply a mechanism that decides which types of IP datagram's will be processed normally and which will be discarded. By discarded we mean that the datagram is deleted and completely ignored, as if it had never been received. You can apply many different sorts of criteria to determine which datagram's you wish to filter; some examples of these are:

- Protocol type: TCP, UDP, ICMP, etc.
- Socket number (for TCP/UPD)
- Datagram type: SYN/ACK, data, ICMP Echo Request, etc.
- Datagram source address: where it came from
- Datagram destination address: where it is going to.

It is important to understand at this point that IP filtering is a network layer facility. This means it doesn't understand anything about the application using the network connections, only about the connections themselves. The IP filtering rule set is made up of many combinations of the criteria listed previously.

Use firewall option to set IP addresses from which is possible remote access on the GWR Router. Demilitarized Zone (DMZ) allows one IP Address to be exposed to the Internet. Because some applications require multiple TCP/IP ports to be open, DMZ provides this function by forwarding all the ports to one computer at the same time. In the other words, this setting allows one local user to be exposed to the Internet to use a special-purpose services such as Internet gaming, Video-conferencing and etc. It is recommended that you set your computer with a static IP if you want to use this function.

IP Filtering	
Label	Description
<i>IP Filtering</i>	
<i>Disable all</i>	This field specifies if Firewall and DMZ settings are disabled at the GWR Router.
<i>Enable Firewall</i>	This field specifies if Firewall is enabled at the GWR Router.
<i>Enable DMZ</i>	This field specifies if DMZ settings is enabled at the GWR Router.
<i>Allow access from the following devices</i>	
<i>Enable</i>	This check box allows/forbidden host to access to the GWR Router.
<i>IP address</i>	This field specifies IP address of the host allow access to the GWR Router.
<i>Service</i>	This field specifies service of the host allow access to the GWR Router.
<i>Protocol</i>	This field specifies protocol of the host allow access to the GWR Router.
<i>Port</i>	This field specifies port of the host allow access to the GWR Router.
<i>Add</i>	Click <i>Add</i> to insert (add) new item in table to the GWR Router.
<i>Remove</i>	Click <i>Remove</i> to delete selected item from table.
<i>Allow access from the following networks</i>	
<i>Enable</i>	This check box allows/forbidden host to access to the GWR Router.
<i>IP address</i>	This field specifies IP address of the host allow access to the GWR Router.
<i>Subnet mask</i>	This field specifies network mask of the network to allow access to the GWR

	Router.
<i>Service</i>	This field specifies service of the host allow access to the GWR Router.
<i>Protocol</i>	This field specifies protocol of the host allow access to the GWR Router.
<i>Port</i>	This field specifies port of the host allow access to the GWR Router.
<i>Add</i>	Click <i>Add</i> to insert (add) new item in table to the GWR Router.
<i>Remove</i>	Click <i>Remove</i> to delete selected item from table.
<b>Demilitarized Zone Host Settings</b>	
<i>MZ Private IP Address</i>	This check box allows/forbidden host to access to the GWR Router.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.
<i>Save</i>	Click <i>Save</i> to save your changes back to the GWR Router.

Table 12 - IP filtering parameters

The screenshot displays the 'IP Filtering' configuration page in the GWR Router Configuration Console. The left sidebar contains a navigation menu with categories: Status (General, Network Information, WAN Information), Settings (Network, DHCP Server, WAN Settings, Routing, Dynamic Routing Protocol, RIP, VPN Settings, GRE, IPSec, Certificates, My Certificates, Trusted CAs, IP Filtering), Maintenance (Administrator Password, Device Identity Settings, Date/Time Settings, Diagnostics, Update Firmware, Settings Backup, Reboot, Default Settings), and Management (Serial Port, SNMP, Logs, Logout). The main content area is titled 'IP Filtering' and includes three radio button options: 'Disable all', 'Enable Firewall' (selected), and 'Enable DMZ'. Under 'Firewall Settings', there is a checkbox for 'Automatically allow access from all devices on the local subnet' which is unchecked. Two tables are present: 'Allow access from the following devices' and 'Allow access from the following networks'. The first table has columns for Enable, IP Address, Service, Protocol, Port, and Action, with entries for 10.0.10.24 (HTTP, TCP, 80) and 10.0.10.24 (Telnet, TCP, 23). The second table has columns for Enable, IP Address, Subnet Mask, Service, Protocol, Port, and Action, with entries for 10.0.10.24 (255.255.255.0, Custom, TCP, 56) and an 'All Traffic' entry. A 'Caution' message states: 'Carefully review settings before applying changes. Incorrect settings can make the GWR Router inaccessible from the network.' Below this is the 'Demilitarized Zone Host Settings' section with a text input for 'DMZ Private IP Address' containing '10.0.10.88' and 'Reload' and 'Save' buttons. The footer contains the copyright notice: 'Copyright © 2008 Geneko. All rights reserved. http://www.geneko.rs/'

Figure 19 - IP Filtering configuration page

IP Filtering configuration example

This example configuration demonstrates how to secure a network with a combination of routers and a GWR Router.




Figure 20 - IP Filtering configuration example

The screenshot shows the 'GWR ROUTER - CONFIGURATION CONSOLE' interface. On the left is a sidebar menu with categories like Status, Settings, Maintenance, and Management. The main area is titled 'IP Filtering' and contains the following sections:

- Radio buttons for:  Disable all,  Enable Firewall,  Enable DMZ.
- A checkbox for 'Automatically allow access from all devices on the local subnet'.
- A section 'Allow access from the following devices:' containing a table:
 

Enable	IP Address	Service	Protocol	Port	Action
<input checked="" type="checkbox"/>	192.168.1.1	ICMP			Rem
<input checked="" type="checkbox"/>	192.168.2.1	All Traffic	TCP/UDP	1-65535	Rem
<input checked="" type="checkbox"/>	192.168.3.1	Custom	TCP	222	Rem
<input checked="" type="checkbox"/>	192.168.4.1	Custom	UDP	69	Rem
<input type="checkbox"/>		All Traffic	TCP/UDP	1-65535	Add
- A section 'Allow access from the following networks:' containing a table:
 

Enable	IP Address	Subnet Mask	Service	Protocol	Port	Action
<input type="checkbox"/>			All Traffic	TCP/UDP	1-65535	Add
- A 'Caution' note: 'Carefully review settings before applying changes. Incorrect settings can make the GWR Router inaccessible from the network.'
- A 'Demilitarized Zone Host Settings' section with a text input for 'DMZ Private IP Address' and 'Reload' and 'Save' buttons.

Figure 21 - IP Filtering settings

## Maintenance

The GWR Router provides administration utilities via web interface. Administrator can setup basic router's parameters, perform network diagnostic, update software or restore factory default settings.

### Maintenance - Administrator Password

By *Administrator Password* Tab it is possible to activate and deactivates device access system through *Username* and *Password* mechanism. Within this menu change of authorization data Username/Password is also done. *Administer Password* Tab window is shown on *Figure 22*.

**NOTE: The password cannot be recovered if it is lost or forgotten. If the password is lost or forgotten, you have to reset the Router to its factory default settings; this will remove all of your configuration changes.**




Figure 22 - Administrator Password configuration page

Administrator Password	
Label	Description
<i>Username</i>	This field specifies Username for user (administrator) login purpose.
<i>Old Password</i>	Enter the old password. The default is <i>admin</i> when you first power up the GWR Router.
<i>Enable Password Authentication</i>	By this check box you can activate or deactivate function for authentication when you access to web/console application.
<i>New Password</i>	Enter a new password for GWR Router. Your password must have 20 or fewer characters and cannot contain any space.
<i>Confirm Password</i>	Re-enter the new password to confirm it.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.

Table 13 - Administrator password

### Maintenance - Device Identity Settings

Within *Device Identity Settings Tab* there is an option to define name, location of device and description of device function. These data are kept in device permanent memory. *Device Identity Settings* window is shown on *Figure 23*.

Device Identity Settings	
Label	Description
<i>Name</i>	This field specifies name of the GWR Router.
<i>Description</i>	This field specifies description of the GWR Router. Only for information purpose.
<i>Location</i>	This field specifies location of the GWR Router. Only for information purpose.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.

Table 14 - Device Identity parameters




Figure 23 - Device Identity Settings configuration page

### Maintenance - Date/Time Settings

To set the local time, select **Date/Time Settings** using the Network Time Protocol (NTP) automatically or Set the local time manually. Date and time setting on the GWR Router are done through window Date/Time Settings.




Figure 24 - Date/Time Settings configuration page

Date/Time Settings	
Label	Description
<i>Set Manually</i>	Sets date and time manually as you specify it.
<i>Time/Date</i>	This field species Date and Time information. You can change date and time by changing parameters.
<i>Sync Clock With Client</i>	Date and time setting on the basis of PC calendar.
<i>From Time Server</i>	Sets the local time using the Network Time Protocol (NTP) automatically.
<i>Time Server Address</i>	Enter the URL or IP address of the NTP server.
<i>Time Zone</i>	Select your time zone.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.

Table 15 - Date/time parameters

## Maintenance - Diagnostics

The GWR Router provide built-it tool, which is used for troubleshooting network problems. The ping test bounces a packet of machine on the Internet back to the sender. This test shows if the GWR Router is able to conect the remote host. If users on the LAN are having problems accessing service on the Internet, try to ping the DNS server or other machine on network.

Click *Diagnostic* tab to provide basic diagnostic tool for testing network connectivity. Insert valid IP address in *Hostname* box and click *Ping*. Every time you click *Ping* router sends four ICMP packets to destination address.

Before using this tool make sure you know the device or host's IP address.



Figure 25 - Diagnostic page

## Maintenance - Update Firmware

You can use this feature to upgrade the GWR Router firmware to the latest version. If you need to download the latest version of the GWR Router firmware, please visit Geneko support site. Follow the on-screen instructions to access the download page for the GWR Router.

If you have already downloaded the firmware onto your computer, click *Browse* button, on *Update firmware* Tab, to look for the firmware file. After selection of new firmware version through *Browse* button, mechanism the process of data transfer from firmware to device itself should be started. This is done by *Upload* button. The process of firmware transfer to the GWR device takes a few minutes and when it is finished the user is informed about transfer process success.

**NOTE: The Router will take a few minutes to upgrade its firmware. During this process, do not power off the Router or press the Reset button.**




Figure 26 - Update Firmware page

In order to activate new firmware version it is necessary that the user performs system reset. In the process of firmware version change all configuration parameters are lost and after that the system continues to operate with default values.

## Maintenance - Settings Backup

This feature allows you to make a backup file of your preferences file for the GWR Router. To save the backup file, you need to export the configuration file. To use the backup preferences file, you need to import the configuration file that you previously exported.

### *Import Configuration File*

To import a configuration file, first specify where your backup configuration file is located. Click **Browse**, and then select the appropriate configuration file.

After you select the file, click Import. This process may take up to a minute. Restart the Router in order to changes will take effect.

### *Export Configuration File*

To export the Router's current configuration file, click **Export**.




Figure 27 - File download

Click **Export**, and then select the location where you want to store your backup configuration file. By default, this file will be called confFile.bkg, but you may rename it if you wish. This process may take up to a minute.

### Maintenance - System Reboot

If you need to restart the Router, Geneko recommends that you use the Reboot tool on this screen. Click **Reboot** to have the GWR Router reboot. This does not affect the router’s configuration.




Figure 28 - System Reboot page

## Maintenance - Default Settings

Use this feature to clear all of your configuration information and restore the GWR Router to its factory default settings. Only use this feature if you wish to discard all the settings and preferences that you have configured.

Click **Default Setting** to have the GWR Router with default parameters. **Keep network settings** check-box allows user to keep all network settings after factory default reset. System will be reset after pressing **Restore** button.




Figure 29 - Default Settings page

## Management - Serial Port

There are two methods which can be used to configure router serial port. Administrator can use following serial port settings:

- Configuration console
- Serial to Ethernet converter

The GWR Router provides a way for a user to connect from a network connection to a serial port. It provides all the serial port setup, a configuration file to configure the ports, a control login for modifying port parameters, monitoring ports, and controlling ports. The GWR Router supports RFC 2217 (remote control of serial port parameters).

Configuration may be performed by serial RS-232C port (DB-9 interface), using following credentials: user "admin" and initial password "admin". Console port allows partial administration, configuration and control options.

The GWR Router serial port configuration:

1. Read and follow the User Manual.
2. Connect a serial console cable to the RJ45 console port.

3. Serial port parameters:
  - Baud rate: 57600,
  - Data bits: 8,
  - Parity: None,
  - Stop bits: 1,
  - Flow control: None.

Click **Serial Port** Tab to open the Serial Port Configuration screen. Use this screen to configure the GWR Router serial port parameters (Figure 30).

The screenshot displays the 'Serial Port' configuration page within the Geneko GWR Router Configuration Console. The page is titled 'Serial Port' and contains a 'Serial Port Settings' section. The settings are as follows:

- Enable configuration console
- Enable serial-ethernet converter
- Bits per second: 57600
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: None
- Bind to port: 223
- Type of socket: raw

At the bottom of the settings area, there is a note: '\* Port: Valid values [1-65535]'. Below the settings are two buttons: 'Reload' and 'Save'.

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 30 - Serial Port configuration page

Serial Port Settings	
Label	Description
<i>Enable configuration console</i>	Enable router configuration console. Default serial port parameters are: Serial port parameters: baud rate - 57600, data bits - 8, parity - none, stop bits - 1, flow control - none.
<i>Enable serial-Ethernet converter</i>	Enable serial to Ethernet converter. This provides a way for a user to connect from a network connection to a serial port.
<i>Bits per second</i>	The unit and attached serial device, such as a modem, must agree on a speed or baud rate to use for the serial connection. Valid baud rates are 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600 or 115200.
<i>Data bits</i>	Indicates the number of bits in a transmitted data package.
<i>Parity</i>	Checks for the parity bit. None is the default.
<i>Stop bits</i>	The stop bit follows the data and parity bits in serial communication. It indicates the end of transmission. The default is 1.
<i>Flow control</i>	Flow control manages data flow between devices in a network to ensure it is processed efficiently. Too much data arriving before a device is prepared to manage it causes lost or retransmitted data. None is the default.
<i>Bind to port</i>	Number of the TCP/IP port to accept connections from for this device.
<i>Type of socket</i>	Either <i>raw</i> , <i>brawl</i> or <i>telnet</i> . <i>raw</i> enables the port and transfers all data as-is between the port and the long. <i>rawlp</i> enables the port and transfers all input data to device, device is open without any termios setting. It allows using printers connected to them. <i>telnet</i> enables the port and runs the telnet protocol on the port to set up telnet parameters. This is most useful for using telnet.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router and activate/deactivate serial to ethernet converter.

Table 16 - Serial port parameters

## Management - Simple Management Protocol (SNMP)

SNMP, or Simple Network Management Protocol, is a network protocol that provides network administrators with the ability to monitor the status of the Router and receive notification of any critical events as they occur on the network. The Router supports SNMP v1/v2c and all relevant Management Information Base II (MIBII) groups. The appliance replies to SNMP Get commands for MIBII via any interface and supports a custom MIB for generating trap messages.




Figure 31 - SNMP configuration page

SNMP Settings	
Label	Description
<i>Enable SNMP</i>	SNMP is enabled by default. To disable the SNMP agent, click this option to unmark.
<i>Get Community</i>	Create the name for a group or community of administrators who can view SNMP data. The default is <b>public</b> . It supports up to 64 alphanumeric characters.
<i>Service Port</i>	Sets the port on which SNMP data has been sent. The default is 161. You can specify port by marking on user defined and specify port you want SNMP data to be sent.
<i>Service Access</i>	Sets the interface enabled for SNMP traps. The default is Both.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router and enable/disable SNMP.

Table 17 - SNMP parameters

### Management - Logs

Syslog is a standard for forwarding log messages in an IP network. The term "syslog" is often used for both the actual syslog protocol, as well as the application or library sending syslog messages.

Syslog is a client/server protocol: the syslog sender sends a small (less than 1KB) textual message to the syslog receiver. Syslog is typically used for computer system management and security auditing. While it has a number of shortcomings, syslog is supported by a wide variety

of devices and receivers across multiple platforms. Because of this, syslog can be used to integrate log data from many different types of systems into a central repository.




Figure 32 - Syslog configuration page

The GWR Router supports this protocol and can send its activity logs to an external server.

Syslog Settings	
Label	Description
<i>Enable Syslog</i>	Mark this option in order to enable Syslog feature.
<i>Service Server</i>	The GWR Router can send a detailed log to an external Syslog server. The Router's Syslog captures all log activities and includes this information about all data transmissions: every connection source and destination IP address, IP service, and number of bytes transferred. Enter the Syslog server name or IP address.
<i>Service Port</i>	Sets the port on which Syslog data has been sent. The default is 514. You can specify port by marking on user defined and specify port you want Syslog data to be sent.
<i>Reload</i>	Click <i>Reload</i> to discard any changes and reload previous settings.
<i>Save</i>	Click <i>Save</i> button to save your changes back to the GWR Router and enable/disable Syslog.

Table 18 - Syslog parameters

## Wizards – Internet Access

This wizard helps you to easily configure the Internet connection. You will be asked through three pages about the parameters for the Internet connection. Click **Internet Access** Tab to open the wizard. Use those screens to configure the GWR Router.

### Step 1

This screen (Figure 33) enables you to configure the LAN settings.

- **IP Address** - In this field you must enter the local LAN address of the router.
- **Netmask** - This is the netmask of the local LAN address of the router.
- **Local DNS** - This field holds the address of the local DNS server that you want to use.

Figure 33 - Internet Access Wizard - page 1 of 3

### Step 2

This screen (Figure 34) enables you to configure the GSM settings.

- **Provider** - Enter the name for the Internet connection.
- **Authentication** - In this menu you can choose the type of the PPP authentication.
- **Username** - Enter the username for your Internet connection. This username is provided by your GSM mobile provider.
- **Password** - Enter the password for your Internet connection. This password is provided by your GSM mobile provider.
- **Dial string** - Enter the dial string for your Internet connection. This dial string is provided by your GSM mobile provider. In most cases you do not need to change this field.
- **Initial string** - Enter the initial string for your Internet connection. This initial string is provided by your GSM mobile provider. In most cases you do not need to change this field, except the APN string which is the Access Point Name of your GSM Internet connection.
- **Pin enabled** - If you have enabled the PIN code on your mobile card, check this box and enter the PIN code.

Figure 34 - Internet Access Wizard - page 2 of 3

**Step 3**

This screen (Figure 35) is a summary of entered parameters on previous pages. If the settings are correct, click on the *Finish* button. If some of parameters are show in red color that parameters are not entered correctly. Please use the *Back* button to enter parameters correctly.




Figure 35 - Internet Access Wizard - page 3 of 3

**Wizards – GRE Tunnel**

This wizard helps you to easily configure the GRE tunnels. You will be asked through four pages about the parameters for the GRE tunnel. Click *GRE Tunnel* Tab to open the wizard. Use those screens to configure the GWR Router.

**Step 1**

This screen (Figure 36) enables you to configure the LAN settings.

- **IP Address** - In this field you must enter the local LAN address of the router.
- **Netmask** - This is the netmask of the local LAN address of the router.
- **Local DNS** - This field holds the address of the local DNS server that you want to use.




Figure 36 - GRE Tunnel Wizard - 1 of 4

**Step 2**

This screen (Figure 37) enables you to configure the GSM settings.

- **Provider** - Enter the name for the Internet connection.
- **Authentication** - In this menu you can choose the type of the PPP authentication.
- **Username** - Enter the username for your Internet connection. This username is provided by your GSM mobile provider.

- **Password** - Enter the password for your Internet connection. This password is provided by your GSM mobile provider.
- **Dial string** - Enter the dial string for your Internet connection. This dial string is provided by your GSM mobile provider. In most cases you do not need to change this field.
- **Initial string** - Enter the initial string for your Internet connection. This initial string is provided by your GSM mobile provider. In most cases you do not need to change this field, except the APN string which is the Access Point Name of your GSM Internet connection.
- **Pin enabled** - If you have enabled the PIN code on your mobile card, check this box and enter the PIN code.

GRE Tunnel wizard - page 2 of 4

This screen enables you to configure the GSM settings.

Provider	telekom
Authentication	PAP-CHAP
Username	mts
Password	064
Dial string	ATD*99***1#
Initial string	at+cgdcont=1,\"IP\",*atets
<input type="checkbox"/> Pin Enabled	1234

Cancel Back Next Finish

Figure 37 - GRE Tunnel Wizard - 2 of 4

### Step 3

This screen (Figure 38) enables you to configure the GRE settings.

- **Local Tunnel Address** - Enter the local IP address of GRE interface.
- **Local Tunnel Netmask** - This field is automatically generated.
- **Tunnel Source** - Enter the IP address of the local WAN interface. If the GSM connection is already established, this field will be automatically generated.
- **Tunnel Destination** - Enter the IP address of the remote WAN interface.
- **Destination Network** - Enter the remote network address which will be available through the GRE tunnel. The route to this address will be inserted automatically.
- **Destination Network Netmask** - Enter the remote network address netmask.

GRE Tunnel wizard - page 3 of 4

This screen enables you to configure the GRE settings.

Local Tunnel Address	10.10.10.1
Local Tunnel Netmask	255.255.255.252
Tunnel Source	172.29.8.6
Tunnel Destination	172.29.8.5
Destination Network	10.0.10.0
Destination Network Netmask	255.255.255.0

Cancel Back Next Finish

Figure 38 - GRE Tunnel Wizard - 3 of 4

### Step 4

This screen (Figure 39) is a summary of entered parameters on previous pages. If the settings are correct, click on the **Finish** button. If some of parameters are show in red color that parameters are not entered correctly. Please use the **Back** button to enter parameters correctly.




Figure 39 - GRE Tunnel Wizard - 4 of 4

### Wizards – IPsec Tunnel

This wizard helps you to easily configure the IPsec tunnels. You will be asked through six pages about the parameters for the IPsec tunnel. Click *IPsec Tunnel* Tab to open the wizard. Use those screens to configure the GWR Router.

#### Step 1

This screen (*Figure 40*) enables you to configure the LAN settings.

- **IP Address** - In this field you must enter the local LAN address of the router.
- **Netmask** - This is the netmask of the local LAN address of the router.
- **Local DNS** - This field holds the address of the local DNS server that you want to use.




Figure 40 - IPsec Tunnel Wizard - 1 of 6

#### Step 2

This screen (*Figure 41*) enables you to configure the GSM settings.

- **Provider** - Enter the name for the Internet connection.
- **Authentication** - In this menu you can choose the type of the PPP authentication.
- **Username** - Enter the username for your Internet connection. This username is provided by your GSM mobile provider.

- **Password** - Enter the password for your Internet connection. This password is provided by your GSM mobile provider.
- **Dial string** - Enter the dial string for your Internet connection. This dial string is provided by your GSM mobile provider. In most cases you do not need to change this field.
- **Initial string** - Enter the initial string for your Internet connection. This initial string is provided by your GSM mobile provider. In most cases you do not need to change this field, except the APN string which is the Access Point Name of your GSM Internet connection.
- **Pin enabled** - If you have enabled the PIN code on your mobile card, check this box and enter the PIN code.

IPsec Tunnel wizard - page 2 of 6

This screen enables you to configure the GSM settings.

Provider	telekom
Authentication	PAP-CHAP
Username	mts
Password	064
Dial string	ATD*99**1#
Initial string	at+cgdcont=1,"IP",ates!
<input type="checkbox"/> Pin Enabled	1234

Buttons: Cancel, Back, Next, Finish

Figure 41 - IPsec Tunnel Wizard - 2 of 6

### Step 3

This screen (*Figure 42*) enables you to configure the Local and Remote Group parameters of the IPsec tunnel.

Local Group Setup:

- **Gateway Type IP Address** - Enter the IP address of the local WAN interface. If the GSM connection is already established, this field will be automatically generated.
- **Local Security Group Type** - You can choose IP or Subnet. In case you want only one host on the local network behind the tunnel you will choose IP. If you want to use a range of addresses choose Subnet.

Remote Group Setup:

- **Gateway Type IP Address** - Enter the IP address of the local WAN interface.
- **Remote Security Group Type** - You can choose IP or Subnet. In case there is only one host on the remote network behind the tunnel you will choose IP. If there is a range of addresses choose Subnet.




Figure 42 - IPsec Tunnel Wizard - 3 of 6

**Step 4**

This screen () enables you to configure the Phase 1, Phase 2 and Pre-Shared Key parameters of the IPsec tunnel.

- **Phase 1 DH Group** - You can choose Group1, Group2 or Group5. Please read the IPSEC section of documentation for the details.
- **Phase 1 Encryption** - You can choose DES, 3DES or AES-128. Please read the IPSEC section of documentation for the details.
- **Phase 1 Authentication** - You can choose MD5 or SHA1. Please read the IPSEC section of documentation for the details.
- **Perfect Forward Secrecy** - Check this box to enable a Perfect Forward Secrecy method. Please read the IPSEC section of documentation for the details.
- **Phase 2 Encryption** - You can choose NULL, DES, 3DES or AES-128. Please read the IPSEC section of documentation for the details.
- **Phase 2 Authentication** - You can choose NULL, MD5 or SHA1. Please read the IPSEC section of documentation for the details.
- **Preshared Key** - Use this field to enter the PreShared Key string. Please read the IPSEC section of documentation for the details.



Figure 43 - IPsec Tunnel Wizard - 4 of 6

Step 5

This screen (Figure 44) enables you to configure advanced parameters of the IPSec tunnel. You can choose a various advanced parameters for the tunnel. Please read IPSEC section of the documentation for the details.




Figure 44 - IPSec Tunnel Wizard - 5 of 6

Step 6

This screen (Figure 45) is a summary of entered parameters on previous pages. If the settings are correct, click on the **Finish** button. If some of parameters are show in red color that parameters are not entered correctly. Please use the **Back** button to enter parameters correctly.




Figure 45 - IPSec Tunnel Wizard - 6 of 6



After successfully finished process of authentication of username/password you can access *Custom Setup* menu - which is shown at *Figure 48*.

For navigation through menu please use following tips. The changes in settings will be applied after pressing "Q" button and process of saving configuration data. If you change network parameters router will reboot after pressing "Q" button and you will have to wait 1 min before it become available again. Press "ESC" button if you want to go back and return to previous menu. If you want to logout and quit console session pres button "L". When you logout you will have to retype username/password if you want to log in router again.

```
*****
*                               Custom Setup                               *
*****
* 1. Network settings           *
* 2. DHCP Server                *
* 3. GPRS/EDGE settings         *
* 4. Routing                     *
* 5. Administration             *
* 6. Status                     *
* 7. Configuration wizard       *
*****
back - ESC; logout - l; exit - q
>
```

Figure 48 - Main configuration menu

## Network Settings

To enter the network configuration, select the *Network settings* menu (*Figure 49*) item in *Custom Setup*. To define the network interface IP address (*IP address*), the network mask (*Netmask*), you can choose between static and dynamic IP configuration option.

```
*****
*                               Network settings                          *
*****
* 1. Use static IP address (Y)   *
* 2. Obtain an IP address automatically (N) *
*****
back - ESC; logout - l; exit - q
>
```

Figure 49 - Network parameters

## Static vs. Dynamic IP Addresses

The demand for public IP addresses continues to grow, yet there are a finite number of public IP addresses available. To solve this problem, wireless carriers have resorted to handing out dynamic IP addresses instead of static or fixed public addresses. With dynamic IP addresses, each device is given an IP address for a limited period of time (usually no more than a few hours), and then the IP address is changed. By using dynamic IP addressing schemes, carriers effectively solve their problem of not having a sufficient quantity of fixed IP addresses to meet market demand. This creates a challenge for users with mobile terminated applications who need a fixed address to target. Fortunately, solutions to all of the challenges above are available using the GWR Router. For example, the network connection type between the carrier's network infrastructure and the customer's data center can provide some flexibility. Also, a frame relay or Virtual Private Network (VPN) connection between the carrier network and the customer's data center allows remote devices to use private IP address assignments for mobile terminated application connections. A static IP can also be maintained by creating a VPN connection to the end device.

If you want manually to configure TCP/IP parameters of the GWR Router choose option 1. You will get page like one on the *Figure 50*.

```

*****
*                               Static                               *
*****
* 1. IP (10.0.10.113)                                                 *
* 2. Netmask (255.255.255.0)                                         *
*****
back - ESC; logout - l; exit - q
>

```

Figure 50 - Network parameters configuration

## DHCP Server Settings

Option 2 in *Custom setup* menu (Figure 48) is DHCP server. This menu (Figure 51) enables you to configure full DHCP server parameters. It is possible to define the beginning - option 2 (*IP Address From*) and end - option 3 (*IP Address To*) of the pool of IP addresses which will be assigned to DHCP clients as well as DNS and excluded IP addresses (currently under construction).

```

*****
*                               DHCP Server                           *
*****
* 1. Enable DHCP (N)                                                 *
* 2. IP Address From (0.0.0.0)                                       *
* 3. IP Address To (0.0.0.0)                                         *
* 4. Address Exclusions                                              *
* 5. Primary DNS (None)                                             *
* 6. Secondary DNS (None)                                           *
* 7. Lease Duration (days: 00 hrs: 08 mins: 20)                   *
*****
back - ESC; logout - l; exit - q
>

```

Figure 51 - DHCP Server configuration

In the DNS submenu of DHCP Server menu you can configure *Primary* and *Secondary DNS* server.

```

*****
*                               Primary DNS                           *
*****
* 1. None                                                            *
* 2. Used by ISP                                                     *
* 3. User defined (0.0.0.0)                                         *
*****
back - ESC; logout - l; exit - q
>

```

Figure 52 - Primary DNS

```

*****
*                               Secondary DNS                          *
*****
* 1. None                                                            *
* 2. Used by ISP                                                     *
* 3. User defined (0.0.0.0)                                         *
*****
back - ESC; logout - l; exit - q
>

```

Figure 53 - Secondary DNS

## GPRS/EDGE/HSDPA Settings

To enter the Wireless network GPRS/EDGE/HSDPA configuration, select the *GPRS/EDGE settings* menu item in *Custom Setup* (Figure 54). You can select for which SIM card you want to enter the parameters (Figure 55).

```

*****
*                GPRS/EDGE settings                *
*****
*  1. SIM card 1                                  *
*  2. SIM card 2                                  *
*****
back - ESC; logout - l; exit - q
>

```

Figure 54 - SIM card selection

Once you choose which SIM card to configure, you can enter initial parameters for GPRS/EDGE/HSDPA access and you can choose authentication type. These parameters you will get from your Mobile provider. The changes in settings will apply after pressing “Q” button and saving configuration data.

```

*****
*                SIM card 1                        *
*****
*  1. Authentication (PAP-CHAP)                   *
*  2. Username (mts)                              *
*  3. Password (064)                              *
*  4. Dial string (at+cgdcont=1,IP,APN1)         *
*  5. Initial string (ATD*99***1#)              *
*  6. Number of retries (6)                      *
*  7. SIM enable (Y)                             *
*****
back - ESC; logout - l; exit - q
>

```

Figure 55 - SIM card GSM/UMTS configuration

```

*****
*                Authentication                    *
*****
*  1. PAP-CHAP                                    *
*  2. PAP                                          *
*  3. CHAP                                        *
*****
back - ESC; logout - l; exit - q
>

```

Figure 56 - GSM/UMTS authentication

## Routing

To enter the Routing configuration, select the *Routing* menu item in *Custom Setup*. In this version of router’s software you are able only to see routing table and not to add/change routes. For add/edit/remove routes please use web configuration.

```

*****
*                Routing                          *
*****
*  1. Routing table                               *
*****
back - ESC; logout - l; exit - q
>

```

Figure 57 - Routing menu

```
*****
*                               Routing table                               *
*****
Destination      Gateway          Genmask          Flags Metric Ref    Use Iface
10.0.0.0         0.0.0.0         255.255.255.0   U      0      0      0 eth0
127.0.0.0       0.0.0.0         255.0.0.0       U      0      0      0 lo
*****
back - ESC; refresh - r; logout - l; exit - q
>
```

Figure 58 - Routing table (list of all routes)

Administration

*Administration* menu is available under option 5 (Figure 48). The changes in settings will apply after pressing “Q” button and saving configuration data.

```
*****
*                               Administration                               *
*****
* 1. Administrator password *
* 2. Diagnostic *
* 3. Date/Time settings *
* 4. Reboot *
* 5. Factory default settings *
*****
back - ESC; logout - l; exit - q
>
```

Figure 59 - Administration Menu

If you want to change default username/password please choose option 1 (*Administrator password*).

```
*****
*                               Administrator password                               *
*****
* 1. Username (admin) *
* 2. Password (admin) *
* 3. Enable password authentication (N) *
*****
back - ESC; logout - l; exit - q
>
```

Figure 60 - Administrator password

The GWR Router has basic diagnostic tool (Ping) for testing network connectivity. If you want to use *Ping utility* please use *Diagnostic* under *Administration* menu (Figure 61).

```
*****
*                               Ping utility                               *
*****
* 1. Ping IP Address of a device (... ) *
* 2. Number of retries (1) *
* 3. Packet size (56) *
* 4. Ping *
*****
back - ESC; logout - l; exit - q
>
```

Figure 61 - Network diagnostic utility

If you want to setup/change time and date parameters choose *Date/time settings* (Figure 62).

```

*****
*                               Date/Time settings                               *
*****
* 1. Date (01.01.1970.)                                                    *
* 2. Time (02:05:27)                                                       *
*****
back - ESC; refresh - r; logout - l; exit - q
>
    
```

Figure 62 - Date/time parameters

If you want to restore factory default settings you have two possibilities. *Factory default settings* can be applied with default network parameters and without default network parameters. The default IP address of the router is 192.168.1.1. Option 1 (*Settings with default network params*) enable you to restore full factory default settings and option 2 (*Settings without default network params*) enable you to restore default settings without changing network parameters.

```

*****
*                               Factory default settings                               *
*****
* 1. Settings with default network params                                  *
* 2. Settings without default network params                               *
*****
back - ESC; logout - l; exit - q
>
    
```

Figure 63 - List of Restore option

### Status

If you want to monitor system and check statuses please choose option *Status* in *Custom* menu. There are options for monitoring LAN and wireless parameters as well as global router parameters.

```

*****
*                               Status                                           *
*****
* 1. General                                                                *
* 2. Network information                                                    *
* 3. GPRS/EDGE information                                                  *
*****
back - ESC; logout - l; exit - q
>
    
```

Figure 64 - Status Menu

### General System Information

The *General* page (*Figure 65*) displays the following information about the GWR Router, which can be useful in device monitoring and troubleshooting.

- **Model** - The model of the GWR Router device.
- **Firmware Version** - The current firmware version. This information may be used to help locate and download new firmware.
- **OS** - The operating system.
- **OS Version** - The current OS version.
- **CPU Utilization** - The amount of CPU resources being used by the GWR Router.
- **Up Time** - The amount of time the GWR Router has been running since it was last powered on or rebooted.
- **Total/Used/Free Memory** - The amount of memory (RAM) available, currently in use, and currently not being used.

- **MAC Address** - A unique network identifier. All network devices are required to have their own unique MAC address. The MAC address is on a sticker on you're the GWR Router. The number is displayed as 12 hexadecimal digits, usually starting with 00:1E:5C.

```

*****
*                               General                               *
*****
* Model:                        GWR251-S                          *
* Firmware version:            1.1.7                            *
* OS:                           Linux                            *
* OS version:                   2.6.8.1-crus2.0.8                *
* CPU utilization:              CirrusLogic ARM9 EP9302 200Mhz    *
* Up time:                       02:07:31                        *
* Total memory:                  29520                           *
* Used memory:                   25784                           *
* Free memory:                   3736                             *
* MAC address:                   00:1E:5C:00:00:02                *
*****
back - ESC; refresh - r; logout - l; exit - q
>

```

Figure 65 - List of basic system parameters

## Network Information

The *Network information* (Figure 66) is used to view more detailed network statistics that may aid in troubleshooting network communication problems. The statistics displayed are those gathered since the tables containing the statistics were last cleared. Descriptions of the network statistics follow.

- **Protocol** - The parameter of networks interface.
- **Address** - Hardware (unique) address of networks interface.
- **Netmask** - Mask of network.
- **Broadcast Address** - Broadcast IP Address.
- **Metric** - Number of routers, over which packet must pass.
- **MAC Address** - A unique network identifier. All network devices are required to have their own unique MAC address. The MAC address is on a sticker on you're the GWR Router. The number is displayed as 12 hexadecimal digits, usually starting with 00:1E:5C.
- **MTU** - Maximal size of packet, which is equipment able transmit.
- **Data received** - The total number of received bytes.
- **Data transmitted** - The total number of transmitted bytes.
- **RX Packets/RX Error Packets/RX Dropped Packets** - The number of received packets, number of errors, dropped packets.
- **TX Packets/TX Error Packets/TX Dropped Packets** - The number of transmitted packets, number of errors, dropped packets.
- **DHCP Server** - Information about DHCP status.

```

*****
*                               Network information                               *
*****
* Protocol:                      Ethernet                                     *
* Address:                       10.0.0.139                               *
* Netmask:                       255.255.255.0                           *
* Broadcast address:             0.0.0.0                               *
* Metric:                        1                                       *
* MAC address:                   00:1E:5C:00:00:02                       *
* MTU:                           1500                                   *
*                               *
* Data received:                 0                                       *
* Data transmitted:             12374                                    *
* RX packets:                   0                                       *
* TX packets:                   400                                       *
* RX error packets:             12374                                    *
* TX error packets:             0                                       *
* RX dropped packets:           0                                       *
* TX dropped packets:           0                                       *
*                               *
* DHCP server:                   Stoped                                   *
*****
back - ESC; refresh - r; logout - l; exit - q
>

```

Figure 66 - Status of LAN network connection

## GPRS/EDGE Information

The *GPRS/EDGE information* page displays the mobile information, mobile connection and mobile statistics about the GWR Router, which can be useful in device monitoring and troubleshooting.

- **Modem Manufacturer** - A character string, null-terminated describing the modem module.
- **Modem Model** - A character string, null-terminated describing the modem module.
- **Modem Serial Number** - A character string, null-terminated used as a unique ID per modem module.
- **Modem Revision** - A character string, null-terminated describing the modem module's firmware version.
- **Operator** - The Mobile operator.
- **Cell ID** - The modem reports this as a 4-hex-digit string. In the mobile statistics it is displayed both as hex and decimal representations. For example: "00C3 (195)"
- **Phone Number** - SIM card phone number.
- **Signal Strength** - Returned as a signed integer value. 0 (zero) indicates no signal. Signal strength is indicated as a negative value in units of dBm. The following scale indicates the signal Strength LED ("bars" of signal strength):
  - -101 or less dBm = Unacceptable (running LED)
  - -100 to -91 dBm = Weak (1 LED)
  - -90 to -81 dBm = Moderate (2 LED)
  - -80 to -75 dBm = Good (3 LED)
  - -74 or better dBm = Excellent (4 LED)
  - 0 is not known or not detectable (running LED)

Signal strength LED will blink when GPRS/EDGE connection is not active. When GPRS/EDGE connection is active Signal strength LED is on. Reset condition will be indicated by blinks of the first and last Signal strength LED. When signal quality is not known or not detectable there will be running LED indication.

- **Protocol** - The parameter of networks interface. PPP interface (active connection to GPRS/EDGE).
- **PPP Address** - The IP address of the PPP connection
- **WAN Address** - The IP address in GPRS/EDGE network provided by the mobile service.
- **Primary DNS Address** - IP address of the primary DNS server provided by the mobile service.
- **Secondary DNS Address** - IP address of the secondary DNS server provided by the mobile service.

- **Data received** - The total number of received bytes.
- **Data transmitted** - The total number of transmitted bytes.
- **RX Packets/ RX Error Packets/ RX Dropped Packets** - The number of received packets, number of errors, dropped packets.
- **TX Packets/TX Error Packets/TX Dropped Packets** - The number of transmitted packets, number of errors, dropped packets.

```

*****
*                GPRS/EDGE information                *
*****
*  Mobile information                                *
*  Modem manufacturer:    SIEMENS                    *
*  Modem model:           SIEMENS MC75              *
*  Modem serial number:   355634003480271          *
*  Modem revision:       REVISION 03.010          *
*  Operator:              YU MOBTEL                *
*  Cell ID:               04C6                    *
*  Phone number:          -                        *
*  Signal strength:      -59dB                    *
*  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *
*  Mobile connection
*  Protocol:              unknown                  *
*  WAN address:           unknown                  *
*  PPP address:           unknown                  *
*  Primary DNS address:   unknown                  *
*  Secondary DNS address: unknown                  *
*  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *  *
*  Mobile statistics
*  Data received:         -                        *
*  Data transmitted:     -                        *
*  RX packets:           -                        *
*  TX packets:           -                        *
*  RX error packets:     -                        *
*  TX error packets:     -                        *
*  RX dropped packets:   -                        *
*  TX dropped packets:   -                        *
*****
back - ESC; refresh - r; logout - l; exit - q
>

```

Figure 67 - GSM/UMTS status

## Configuration Wizard

To enter the Configuration wizard, select the *Configuration wizard* menu item in *Custom Setup*. In this version of router's software you are able only to see routing table and not to add/change routes. For add/edit/remove routes please use web configuration.

```

*****
*                Configuration wizard                *
*****
*  1. Internet configuration                          *
*  2. VPN/GRE tunneling                             *
*****
back - ESC; logout - l; exit - q
>

```

Figure 68 - Configuration wizard

## Configuration Example

### GWR Router as Internet Router

The GWR Routers can be used as *Internet router* for a single user or for a group of users (entire LAN). NAT function is enabled by default on the GWR Router. The GWR Router uses Network Address Translation (NAT) where only the mobile IP address is visible to the outside world. All outgoing traffic uses the GWR Router mobile IP address.




Figure 69 - GWR Router as Internet router

- Click **Network** Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP address: 10.1.1.1
  - Netmask: 255.255.255.0
- Press **Save** to accept the changes.
- Use SIM card with a dynamic/static IP address, obtained from Mobile Operator. (Note the default gateway may show, or change to, an address such as 10.0.0.1; this is normal as it is the GSM/UMTS provider's network default gateway).
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Check **Routing** Tab to see if there is default route (should be there by default).
- Router will automatically add default route via `ppp0` interface.
- Optionally configure IP Filtering and TCP service port settings to block any unwanted incoming traffic.
- Configure the GWR Router LAN address (10.1.1.1) as a default gateway address on your PCs. Configure valid DNS address on your PCs.

## GRE Tunnel configuration between two GWR Routers

GRE tunnel is a type of a VPN tunnels, but it isn't a secure tunneling method. On the diagram below (Figure 70) is illustrated simple network with two GWR Routers. Idea is to create GRE tunnel for LAN to LAN (site to site) connectivity.




Figure 70 - GRE tunnel between two GWR Routers

The GWR Routers requirements:

- Static IP WAN address for tunnel source and tunnel destination address;
- Source tunnel address should have static WAN IP address;
- Destination tunnel address should have static WAN IP address;

**GSM/UMTS APN Type:** For GSM/UMTS networks GWR Router connections may require a Custom APN. A Custom APN allows for various IP addressing options, particularly static IP addresses, which are needed for most VPN connections. A custom APN should also support mobile terminated data that may be required in most site-to-site VPNs.

The GWR Router 1 configuration:

- Click **Network** Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 192.168.4.1
  - Subnet Mask: 255.255.255.0
  - Press **Save** to accept the changes.

geneko  
HARDWARE

GWR ROUTER – CONFIGURATION CONSOLE

**Status**  
General  
Network Information  
WAN Information

**Settings**  
Network  
DHCP Server  
WAN Settings  
Routing  
Dynamic Routing Protocol  
RIP  
VPN Settings  
GRE  
IP Filtering

**Maintenance**  
Administrator Password  
Device Identity Settings  
Date/Time Settings  
Diagnostics  
Update Firmware  
Settings Backup  
Reboot  
Default Settings

**Management**  
Serial Port  
SNMP  
Logs

Logout

**Network**

Obtain an IP address automatically using DHCP

Use the following IP address:

IP Address

Subnet Mask

Local DNS

Reload Save

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 71 - Network configuration page for GWR Router 1

- Use SIM card with a static IP address, obtained from Mobile Operator. (Note the default gateway may show, or change to, an address such as 10.0.0.1; this is normal as it is the GSM/UMTS provider's network default gateway).
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Click **VPN Settings > GRE** to configure GRE tunnel parameters:
  - Enable: yes
  - Local Tunnel Address: 10.10.10.1
  - Local Tunnel Netmask: 255.255.255.252 (Unchangeable, always 255.255.255.252)
  - Tunnel Source: 10.251.49.2
  - Tunnel Destination: 10.251.49.3
  - KeepAlive enable: no
  - Period:(none)
  - Retries:(none)
  - Press **ADD** to put GRE tunnel rule into GRE table.
  - Press **Save** to accept the changes.



Figure 72 - GRE configuration page for GWR Router 1

- Click **Routing** on **Settings** Tab to configure GRE Route. Parameters for this example are:
  - Destination Network: 192.168.2.0
  - Netmask: 255.255.255.0
  - Interface: gre\_x




Figure 73 - Routing configuration page for GWR Router 1

- Optionally configure IP Filtering and TCP service port settings to block any unwanted incoming traffic.
- On the device connected on GWR router 1 setup default gateway 192.168.4.1

The GWR Router 2 configuration:

- Click **Network** Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 192.168.2.1
  - Subnet Mask: 255.255.255.0
  - Press **Save** to accept the changes.

Figure 74 - Network configuration page for GWR Router 2

- Use SIM card with a static IP address, obtained from Mobile Operator. (Note the default gateway may show, or change to, an address such as 10.0.0.1; this is normal as it is the GSM/UMTS provider's network default gateway).
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Click **VPN Settings > GRE** to configure GRE tunnel parameters:
  - Enable: yes
  - Local Tunnel Address: 10.10.10.2
  - Local Tunnel Netmask: 255.255.255.252 (Unchangeable, always 255.255.255.252)
  - Tunnel Source: 10.251.49.3
  - Tunnel Destination: 10.251.49.2
  - KeepAlive enable: no
  - Period:(none)
  - Retries:(none)
  - Press **ADD** to put GRE tunnel rule into GRE table.
  - Press **Save** to accept the changes.



Figure 75 - GRE configuration page for GWR Router 2

- Configure GRE Route. Click **Routing** on **Settings** Tab. Parameters for this example are:
  - Destination Network: 192.168.4.0
  - Netmask: 255.255.255.0




Figure 76 - Routing configuration page for GWR Router 2

- Optionally configure IP Filtering and TCP service port settings to block any unwanted incoming traffic.
- On the device connected on GWR router 2 setup default gateway 192.168.2.1

## GRE Tunnel configuration between GWR Router and third party router

GRE tunnel is a type of a VPN tunnels, but it isn't a secure tunneling method. However, you can encrypt GRE packets with an encryption protocol such as IPSec to form a secure VPN.

On the diagram below (Figure 77) is illustrated simple network with two sites. Idea is to create GRE tunnel for LAN to LAN (site to site) connectivity.




Figure 77 - GRE tunnel between Cisco router and GWR Router

GRE tunnel is created between Cisco router with GRE functionality on the HQ Site and the GWR Router on the Remote Network. In this example, it is necessary for both routers to create tunnel interface (virtual interface). This new tunnel interface is its own network. To each of the routers, it appears that it has two paths to the remote physical interface and the tunnel interface (running through the tunnel). This tunnel could then transmit unroutable traffic such as NetBIOS or AppleTalk.

The GWR Router uses Network Address Translation (NAT) where only the mobile IP address is visible to the outside. All outgoing traffic uses the GWR Router WAN/VPN mobile IP address. HQ Cisco router acts like gateway to remote network for user in corporate LAN. It also performs function of GRE server for termination of GRE tunnel. The GWR Router act like default gateway for Remote Network and GRE server for tunnel.

1. HQ router requirements:
  - HQ router require static IP WAN address;
  - Router or VPN appliance have to support GRE protocol;
  - Tunnel peer address will be the GWR Router WAN's mobile IP address. For this reason, a static mobile IP address is preferred on the GWR Router WAN (GPRS) side;
  - Remote Subnet is remote LAN network address and Remote Subnet Mask is subnet of remote LAN.

2. The GWR Router requirements:

- Static IP WAN address;
- Peer Tunnel Address will be the HQ router WAN IP address (static IP address);
- Remote Subnet is HQ LAN IP address and Remote Subnet Mask is subnet mask of HQ LAN.

**GSM/UMTS APN Type:** For GSM/UMTS networks GWR Router connections may require a Custom APN. A Custom APN allows for various IP addressing options, particularly static IP addresses, which are needed for most VPN connections. A custom APN should also support mobile terminated data that may be required in most site-to-site VPNs.

Cisco router sample Configuration:

```
Interface FastEthernet 0/1
ip address 10.2.2.1 255.255.255.0
description LAN interface

interface FastEthernet 0/0
ip address 195.178.54.1 255.255.255.0
description WAN interface

interface Tunnel0
ip address 10.1.1.1 255.255.255.0
tunnel source FastEthernet0/0
tunnel destination 195.200.200.2

ip route 10.1.1.0 255.255.255.0 tunnel0
```

The GWR Router Sample Configuration:

- Click **Network** Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 10.1.1.1
  - Subnet Mask: 255.255.255.0
  - Press **Save** to accept the changes.

The screenshot shows the 'Network' configuration page in the Geneko GWR Router Configuration Console. The page is divided into a left sidebar with navigation menus and a main content area. The sidebar includes sections for Status, Settings, Maintenance, and Management. The main content area is titled 'Network' and contains two radio button options: 'Obtain an IP address automatically using DHCP' (unselected) and 'Use the following IP address:' (selected). Below the selected option are three input fields: 'IP Address' with the value '10.1.1.1', 'Subnet Mask' with the value '255.255.255.0', and 'Local DNS' with the value '195.178.6.36'. At the bottom right of the main content area are two buttons: 'Reload' and 'Save'. At the bottom center of the page, there is a copyright notice: 'Copyright © 2008 Geneko. All rights reserved. http://www.geneko.co.rs/'.

Figure 78 - Network configuration page

- Use SIM card with a dynamic/static IP address, obtained from Mobile Operator. (Note the default gateway may show, or change to, an address such as 10.0.0.1; this is normal as it is the GSM/UMTS provider's network default gateway).
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Click **VPN Settings > GRE Tunneling** to configure new VPN tunnel parameters:
  - Enable: yes
  - Local Tunnel Address: 10.1.1.1
  - Local Tunnel Netmask: 255.255.255.252 (Unchangeable, always 255.255.255.252)
  - Tunnel Source: 195.200.200.2
  - Tunnel Destination: 195.178.54.1
  - KeepAlive enable: no
  - Period:(none)
  - Retries:(none)
  - Press **ADD** to put GRE tunnel rule into VPN table.
  - Press **Save** to accept the changes.

**VPN Settings - GRE**

**Generic Routing Encapsulation (GRE) Tunneling**

Enable	Local Tunnel Address	Local Tunnel Netmask	Tunnel Source	Tunnel Destination	Interface	KeepAlive Enable	Period	Retries	Action
<input checked="" type="checkbox"/>	10.1.1.1	255.255.255.252	195.200.200.2	195.178.54.1	gre1	<input type="checkbox"/>			Rem
<input type="checkbox"/>						<input type="checkbox"/>			Add

Local Tunnel Address: IP Address of virtual tunnel interface  
 Local Tunnel Netmask: (Unchangeable, always 255.255.255.252)  
 Tunnel Source: IP address of tunnel source  
 Tunnel Destination: IP address of tunnel destination  
 Period: Valid values [3-60]  
 Retries: Valid values [1-10]

Reload Save

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.co.rs/>

Figure 79 - GRE configuration page

- Configure GRE Route. Click **Routing** on **Settings** Tab. Parameters for this example are:
  - Destination Network: 10.2.2.0
  - Netmask: 255.255.255.0

**Routing**

Routing table (Local network):

Enable	Dest Network	Netmask	Gateway	Metric	Interface
<input checked="" type="checkbox"/>	10.0.0.1	255.255.255.255	*	0	ppp0
<input checked="" type="checkbox"/>	10.0.10.0	255.255.255.0	*	0	eth0

Routing table:

Enable	Dest Network	Netmask	Gateway	Metric	Interface	Action
<input checked="" type="checkbox"/>	0.0.0.0	0.0.0.0		1	ppp0	Rem
<input checked="" type="checkbox"/>	10.2.2.0	255.255.255.0		1	gre1	Rem
<input type="checkbox"/>					eth0	Add

Forward protocol connections from external networks to the following internal devices:

Enable	Tunneling Protocol	Send to
<input type="checkbox"/>	GRE	10.0.0.1
<input type="checkbox"/>	ESP	10.0.0.2

Forward TCP/UDP connections from external networks to the following internal devices:

Enable	Protocol	Source Port	Dest IP Address	Destination Port	Action
<input type="checkbox"/>	TCP				Add

Reload Save

Figure 80 - Routing configuration page

- Optionally configure IP Filtering and TCP service port settings to block any unwanted incoming traffic.

User from remote LAN should be able to communicate with HQ LAN.

## IPSec Tunnel configuration between two GWR Routers

IPSec tunnel is a type of a VPN tunnels with a secure tunneling method. On the diagram below *Figure 81* is illustrated simple network with two GWR Routers. Idea is to create IPSec tunnel for LAN to LAN (site to site) connectivity.




Figure 81 - IPSec tunnel between two GWR Routers

The GWR Routers requirements:

- Static IP WAN address for tunnel source and tunnel destination address;
- Source tunnel address should have static WAN IP address;
- Destination tunnel address should have static WAN IP address;

**GSM/UMTS APN Type:** For GSM/UMTS networks GWR Router connections may require a Custom APN. A Custom APN allows for various IP addressing options, particularly static IP addresses, which are needed for most VPN connections. A custom APN should also support mobile terminated data that may be required in most site-to-site VPNs.

The GWR Router 1 configuration:

- Click *Network* Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 10.0.10.1
  - Subnet Mask: 255.255.255.0
  - Press *Save* to accept the changes.




Figure 82 - Network configuration page for GWR Router 1

- Use SIM card with a static IP address, obtained from Mobile Operator.
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Click **VPN Settings > IPSEC** to configure IPSEC tunnel parameters. Click **Add New Tunnel** button to create new IPsec tunnel. Tunnel parameters are:
  - **Add New Tunnel**
    - Tunnel Name: test
    - Enable: true
  - **Local Group Setup**
    - Local Security Gateway Type: IP Only
    - IP Address: 172.29.8.4
    - Local Security Group Type: IP
    - IP Address: 10.0.10.1
  - **Remote Group Setup**
    - Remote Security Gateway Type: IP Only
    - IP Address: 172.29.8.5
    - Remote Security Group Type: IP
    - IP Address: 192.168.10.1
  - **IPSec Setup**
    - Keying Mode: IKE with Preshared key
    - Phase 1 DH group: Group 1
    - Phase 1 Encryption: DES
    - Phase 1 Authentication: MD5
    - Phase 1 SA Life Time: 28800
    - Perfect Forward Secrecy: true
    - Phase 2 DH group: Group 1
    - Phase 2 Encryption: DES
    - Phase 2 Authentication: MD5
    - Phase 2 SA Life Time: 3600
    - Preshared Key: 1234567890

- *Advanced*
  - Aggressive Mode: true
  - Compress(Support IP Payload Compression Protocol(IPComp)): false
  - Dead Peer Detection(DPD): false
  - NAT Traversal: true
  - Press *Save* to accept the changes.

Device 2 Device Tunnel

Add New Tunnel

Tunnel Number:

Tunnel Name:

Enable:

---

Local Group Setup

Local Security Gateway Type:

IP Address:

Local Security Group Type:

IP Address:

---

Remote Group Setup

Remote Security Gateway Type:

IP Address:

Remote Security Group Type:

IP Address:

Figure 83 - IPSEC configuration page I for GWR Router 1

IPSec Setup

Keying Mode:

Phase 1 DH Group:

Phase 1 Encryption:

Phase 1 Authentication:

Phase 1 SA Life Time:  seconds

Perfect Forward Secrecy:

Phase 2 DH Group:

Phase 2 Encryption:

Phase 2 Authentication:

Phase 2 SA Life Time:  seconds

Preshared Key:

---

Advanced

Aggressive Mode

Compress (Support IP Payload Compression Protocol (IPComp))

Dead Peer Deection (DPD)  sec

NAT Traversal

Figure 84 - IPSec configuration page II for GWR Router 1

- Click **Start** button on *Internet Protocol Security* page to initiate IPSEC tunnel.

**Internet Protocol Security**

**Summary**

Tunnels Used: 1  
Tunnels Available: 5

No.	Name	Enabled	Status	Enc/ Auth/ Grp	Advanced Setup	Local Group	Remote Group	Remote Gateway	Action
2	test	no	stopped	Ph1: DES/MD5/1 Ph2: DES/MD5/1	A/N	10.0.10.1	192.168.10.1	172.29.8.5	<a href="#">Delete</a> <a href="#">Edit</a>

\* Reducing the MTU size on the client side, can help eliminate some connectivity problems occurring at the protocol level  
 \*\* Recommended MTU size on client side 1300  
 \*\*\* Press Refresh button to re-check IPsec tunnels' status  
 \*\*\*\* Tunnel status description:  
 started - ipsec is running and tunnel's waiting for other end to connect  
 established - tunnel is up  
 deleted - tunnel is down  
 stopped - ipsec is not running or tunnel is not enabled

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.rs/>

Figure 85 – IPsec start/stop page for GWR Router 1

- On the device connected on GWR router 1 setup default gateway 10.0.10.1

The GWR Router 2 configuration:

- Click **Network** Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 192.168.10.1
  - Subnet Mask: 255.255.255.0
  - Press **Save** to accept the changes.

The screenshot shows the 'Network' configuration page in the Geneko GWR Router Configuration Console. The page has a blue header with the Geneko logo and 'GWR ROUTER - CONFIGURATION CONSOLE'. On the left is a navigation menu with categories: Status (General, Network Information, WAN Information), Settings (Network, DHCP Server, WAN Settings, Routing, Dynamic Routing Protocol, RIP, VPN Settings, GRE, IPsec, IP Filtering), Maintenance (Administrator Password, Device Identity Settings, Date/Time Settings, Diagnostics, Update Firmware, Settings Backup, Reboot, Default Settings), Management (Serial Port, SNMP, Logs), and Wizards (Internet Access, GRE Tunnel, IPsec Tunnel), and a Logout link. The main content area is titled 'Network' and contains two radio buttons: 'Obtain an IP address automatically using DHCP' (unselected) and 'Use the following IP address:' (selected). Below the second option are three input fields: 'IP Address' with '192.168.10.1', 'Subnet Mask' with '255.255.255.0', and 'Local DNS' with '195.78.6.36'. At the bottom right of the form are 'Reload' and 'Save' buttons. A copyright notice at the bottom center reads 'Copyright © 2008 Geneko. All rights reserved. http://www.geneko.rs/'.

Figure 86 - Network configuration page for GWR Router 2

- Use SIM card with a static IP address, obtained from Mobile Operator.
- Click **WAN Settings** Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (**WAN Settings** Tab). If disconnected please click **Connect** button.
- Click **VPN Settings > IPSEC** to configure IPSEC tunnel parameters. Click **Add New Tunnel** button to create new IPsec tunnel. Tunnel parameters are:
  - **Add New Tunnel**
    - Tunnel Name: test
    - Enable: true
  - **Local Group Setup**
    - Local Security Gateway Type: IP Only
    - IP Address: 172.29.8.5
    - Local Security Group Type: IP
    - IP Address: 192.168.10.1
  - **Remote Group Setup**
    - Remote Security Gateway Type: IP Only
    - IP Address: 172.29.8.4
    - Remote Security Group Type: IP
    - IP Address: 10.0.10.1
  - **IPsec Setup**
    - Keying Mode: IKE with Preshared key
    - Phase 1 DH group: Group 1
    - Phase 1 Encryption: DES
    - Phase 1 Authentication: MD5
    - Phase 1 SA Life Time: 28800
    - Perfect Forward Secrecy: true
    - Phase 2 DH group: Group 1
    - Phase 2 Encryption: DES
    - Phase 2 Authentication: MD5

- Phase 2 SA Life Time: 3600
- Preshared Key: 1234567890
- **Advanced**
  - Aggressive Mode: true
  - Compress(Support IP Payload Compression Protocol(IPComp)): false
  - Dead Peer Detection(DPD): false
  - NAT Traversal: true
  - Press **Save** to accept the changes.

Device 2 Device Tunnel

Add New Tunnel

Tunnel Number:

Tunnel Name:

Enable:

---

Local Group Setup

Local Security Gateway Type:

IP Address:

Local Security Group Type:

IP Address:

---

Remote Group Setup

Remote Security Gateway Type:

IP Address:

Remote Security Group Type:

IP Address:

Figure 87 - IPSEC configuration page I for GWR Router 2

IPSec Setup

Keying Mode:

Phase 1 DH Group:

Phase 1 Encryption:

Phase 1 Authentication:

Phase 1 SA Life Time:  seconds

Perfect Forward Secrecy:

Phase 2 DH Group:

Phase 2 Encryption:

Phase 2 Authentication:

Phase 2 SA Life Time:  seconds

Preshared Key:

---

Advanced

Aggressive Mode

Compress (Support IP Payload Compression Protocol (IPComp))

Dead Peer Deection (DPD)  sec

NAT Traversal

Figure 88 - IPSEC configuration page II for GWR Router 2

- Click **Start** button on *Internet Protocol Security* page to initiate IPSEC tunnel.

**Internet Protocol Security**

Summary

Tunnels Used: 1  
Tunnels Available: 5

No.	Name	Enabled	Status	Enc/ Auth/ Grp	Advanced Setup	Local Group	Remote Group	Remote Gateway	Action
2	test	no	stopped	Ph1: DES/MD5/1 Ph2: DES/MD5/1	A/N	10.0.10.1	192.168.10.1	172.29.8.5	<a href="#">Delete</a> <a href="#">Edit</a>

\* Reducing the MTU size on the client side, can help eliminate some connectivity problems occurring at the protocol level  
 \*\* Recommended MTU size on client side 1300  
 \*\*\* Press Refresh button to re-check IPsec tunnels' status  
 \*\*\*\* Tunnel status description:  
 started - ipsec is running and tunnel's waiting for other end to connect  
 established - tunnel is up  
 deleted - tunnel is down  
 stopped - ipsec is not running or tunnel is not enabled

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.rs/>

Figure 89 – IPsec start/stop page for GWR Router 2

- On the device connected on GWR router 2 setup default gateway 192.168.10.1.

## IPSec Tunnel configuration between GWR Router and Cisco Router

IPSec tunnel is a type of a VPN tunnels with a secure tunneling method. On the diagram below *Figure 90* is illustrated simple network with GWR Router and Cisco Router. Idea is to create IPSec tunnel for LAN to LAN (site to site) connectivity.




Figure 90 - IPSec tunnel between GWR Router and Cisco Router

The GWR Routers requirements:

- Static IP WAN address for tunnel source and tunnel destination address;
- Source tunnel address should have static WAN IP address;
- Destination tunnel address should have static WAN IP address;

**GSM/UMTS APN Type:** For GSM/UMTS networks GWR Router connections may require a Custom APN. A Custom APN allows for various IP addressing options, particularly static IP addresses, which are needed for most VPN connections. A custom APN should also support mobile terminated data that may be required in most site-to-site VPNs.

The GWR Router configuration:

- Click *Network* Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 192.168.10.1
  - Subnet Mask: 255.255.255.0
  - Press *Save* to accept the changes.

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.rs/>

Figure 91 - Network configuration page for GWR Router

- Use SIM card with a static IP address, obtained from Mobile Operator.
- Click *WAN Settings* Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (*WAN Settings* Tab). If disconnected please click *Connect* button.
- Click *VPN Settings* > *IPSEC* to configure IPSEC tunnel parameters. Click *Add New Tunnel* button to create new IPsec tunnel. Tunnel parameters are:
  - *Add New Tunnel*
    - Tunnel Name: test
    - Enable: true
  - *Local Group Setup*
    - Local Security Gateway Type: IP Only
    - IP Address: 172.30.147.96
    - Local Security Group Type: Subnet
    - IP Address: 192.168.10.0
    - Subnet Mask: 255.255.255.0
  - *Remote Group Setup*
    - Remote Security Gateway Type: IP Only
    - IP Address: 150.160.170.1
    - Remote Security Group Type: IP
    - IP Address: 10.10.10.0
    - Subnet Mask: 255.255.255.0
  - *IPSec Setup*
    - Keying Mode: IKE with Preshared key
    - Phase 1 DH group: Group 2
    - Phase 1 Encryption: 3DES
    - Phase 1 Authentication: SHA1
    - Phase 1 SA Life Time: 28800
    - Perfect Forward Secrecy: true
    - Phase 2 DH group: Group 2

- Phase 2 Encryption: 3DES
- Phase 2 Authentication: SHA1
- Phase 2 SA Life Time: 3600
- Preshared Key: 1234567890
- **Advanced**
  - Aggressive Mode: true
  - Compress(Support IP Payload Compression Protocol(IPComp)): false
  - Dead Peer Detection(DPD): false
  - NAT Traversal: true
  - Press *Save* to accept the changes.
  -

Device 2 Device Tunnel

Add New Tunnel

Tunnel Number	<input type="text" value="2"/>
Tunnel Name	<input type="text" value="test"/>
Enable	<input checked="" type="checkbox"/>

---

Local Group Setup

Local Security Gateway Type	<input type="text" value="IP Only"/>
IP Address	<input type="text" value="172.30.147.96"/>
Local Security Group Type	<input type="text" value="Subnet"/>
IP Address	<input type="text" value="192.168.10.0"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>

---

Remote Group Setup

Remote Security Gateway Type	<input type="text" value="IP Only"/>
IP Address	<input type="text" value="150.160.170.1"/>
Remote Security Group Type	<input type="text" value="Subnet"/>
IP Address	<input type="text" value="10.10.10.0"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>

Figure 92 - IPSEC configuration page I for GWR Router

### IPSec Setup

Keying Mode: IKE with Preshared key

Phase 1 DH Group: Group2

Phase 1 Encryption: 3DES

Phase 1 Authentication: SHA1

Phase 1 SA Life Time: 28800 seconds

Perfect Forward Secrecy:

Phase 2 DH Group: Group2

Phase 2 Encryption: 3DES

Phase 2 Authentication: SHA1

Phase 2 SA Life Time: 3600 seconds

Preshared Key: 1234567890

---

### Advanced

Aggressive Mode

Compress (Support IP Payload Compression Protocol (IPComp))

Dead Peer Deection (DPD)   sec

NAT Traversal

Back
Reload
Save

Figure 93 - IPSec configuration page II for GWR Router

- Click **Start** button on **Internet Protocol Security** page to initiate IPSEC tunnel.

GWR ROUTER - CONFIGURATION CONSOLE

**Status**

General

Network Information

WAN Information

**Settings**

Network

DHCP Server

WAN Settings

Routing

Dynamic Routing Protocol

RIP

VPN Settings

GRE

IPSec

IP Filtering

**Maintenance**

Administrator Password

Device Identity Settings

Date/Time Settings

Diagnostics

Update Firmware

Settings Backup

Reboot

Default Settings

**Management**

Serial Port

SNMP

Logs

**Wizards**

Internet Access

GRE Tunnel

IPSec Tunnel

Logout

Internet Protocol Security

Summary

Tunnels Used: 1

Tunnels Available: 5

Add New Tunnel

No.	Name	Enabled	Status	Enc/Auth/Grp	Advanced Setup	Local Group	Remote Group	Remote Gateway	Action
2	test	yes	started	Ph1: 3DES/SHA1/2 Ph2: 3DES/SHA1/2	A/N	192.168.10.0 255.255.255.0	10.10.10.0 255.255.255.0	150.160.170.1	<a href="#">Delete</a> <a href="#">Edit</a>

Start
Stop
Refresh

\*\*\* Reducing the MTU size on the client side, can help eliminate some connectivity problems occurring at the protocol level

\*\*\* Recommended MTU size on client side 1300

\*\*\* Press Refresh button to re-check IPSec tunnels' status

\*\*\*\*\* Tunnel status description:

started - ipsec is running and tunnel's waiting for other end to connect

established - tunnel is up

deleted - tunnel is down

stopped - ipsec is not running or tunnel is not enabled

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.rs/>

Figure 94 - IPSec start/stop page for GWR Router

- On the device connected on GWR router setup default gateway 192.168.10.1.

The Cisco Router configuration:

```

version 12.4
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname Cisco-Router
!
boot-start-marker
boot-end-marker
!
username admin password 7 *****
!
enable secret 5 *****
!
no aaa new-model
!
no ip domain lookup
!
!--- Keyring that defines wildcard pre-shared key.
!
crypto keyring remote
  pre-shared-key address 0.0.0.0 0.0.0.0 key 1234567890
!
!--- ISAKMP policy
!
crypto isakmp policy 10
  encr 3des
  authentication pre-share
  group 2
  lifetime 28800
!
!--- Profile for LAN-to-LAN connection, that references
!--- the wildcard pre-shared key and a wildcard identity
!
crypto isakmp profile L2L
  description LAN to LAN vpn connection
  keyring remote
  match identity address 0.0.0.0
!
!
crypto ipsec transform-set testGWR esp-3des esp-sha-hmac
!
!--- Instances of the dynamic crypto map
!--- reference previous IPsec profile.
!
crypto dynamic-map dynGWR 5
  set transform-set testGWR
  set isakmp-profile L2L
!
!--- Crypto-map only references instances of the previous dynamic crypto map.
!
crypto map GWR 10 ipsec-isakmp dynamic dynGWR
!
interface FastEthernet0/0
description WAN INTERFACE
ip address 150.160.170.1 255.255.255.252
ip nat outside
no ip route-cache
no ip mroute-cache
duplex auto
speed auto
  crypto map GWR
!
interface FastEthernet0/1
description LAN INTERFACE
ip address 10.10.10.1 255.255.255.0
ip nat inside
no ip route-cache
no ip mroute-cache
duplex auto
speed auto
!
ip route 0.0.0.0 0.0.0.0 150.160.170.2

```

```
!  
ip http server  
no ip http secure-server  
ip nat inside source list nat_list interface FastEthernet0/0 overload  
!  
ip access-list extended nat_list  
deny ip 10.10.10.0 0.0.0.255 192.168.10.0 0.0.0.255  
permit ip 10.10.10.0 0.0.0.255 any  
!  
access-list 23 permit any  
!  
line con 0  
line aux 0  
line vty 0 4  
access-class 23 in  
privilege level 15  
login local  
transport input telnet ssh  
line vty 5 15  
access-class 23 in  
privilege level 15  
login local  
transport input telnet ssh  
!  
end
```

Use this section to confirm that your configuration works properly. Debug commands that run on the Cisco router can confirm that the correct parameters are matched for the remote connections.

- **show ip interface** – Displays the IP address assignment to the spoke router.
- **show crypto isakmp sa detail** – Displays the IKE SAs, which have been set-up between the IPsec initiators.
- **show crypto ipsec sa** – Displays the IPsec SAs, which have been set-up between the IPsec initiators.
- **debug crypto isakmp** – Displays messages about Internet Key Exchange (IKE) events.
- **debug crypto ipsec** – Displays IPsec events.
- **debug crypto engine** – Displays crypto engine events.

## IPSec Tunnel configuration between GWR Router and Juniper SSG firewall

IPSec tunnel is a type of a VPN tunnels with a secure tunneling method. On the diagram below *Figure 95* is illustrated simple network with GWR Router and Cisco Router. Idea is to create IPSec tunnel for LAN to LAN (site to site) connectivity.




Figure 95 - IPSec tunnel between GWR Router and Cisco Router

The GWR Routers requirements:

- Static IP WAN address for tunnel source and tunnel destination address;
- Source tunnel address should have static WAN IP address;
- Destination tunnel address should have static WAN IP address;

**GSM/UMTS APN Type:** For GSM/UMTS networks GWR Router connections may require a Custom APN. A Custom APN allows for various IP addressing options, particularly static IP addresses, which are needed for most VPN connections. A custom APN should also support mobile terminated data that may be required in most site-to-site VPNs.

The GWR Router configuration:

- Click *Network* Tab, to open the **LAN NETWORK** screen. Use this screen to configure LAN TCP/IP settings. Configure IP address and Netmask.
  - IP Address: 192.168.10.1
  - Subnet Mask: 255.255.255.0
  - Press *Save* to accept the changes.




Figure 96 - Network configuration page for GWR Router

- Use SIM card with a static IP address, obtained from Mobile Operator.
- Click *WAN Settings* Tab to configure parameters necessary for GSM/UMTS connection. All parameters necessary for connection configuration should be required from mobile operator.
- Check the status of GSM/UMTS connection (*WAN Settings* Tab). If disconnected please click *Connect* button.
- Click *VPN Settings* > *IPSEC* to configure IPSEC tunnel parameters. Click *Add New Tunnel* button to create new IPsec tunnel. Tunnel parameters are:
  - *Add New Tunnel*
    - Tunnel Name: test
    - Enable: true
  - *Local Group Setup*
    - Local Security Gateway Type: IP Only
    - IP Address: 172.30.147.96
    - Local Security Group Type: Subnet
    - IP Address: 192.168.10.0
    - Subnet Mask: 255.255.255.0
  - *Remote Group Setup*
    - Remote Security Gateway Type: IP Only
    - IP Address: 150.160.170.1
    - Remote Security Group Type: IP
    - IP Address: 10.10.10.0
    - Subnet Mask: 255.255.255.0
  - *IPsec Setup*
    - Keying Mode: IKE with Preshared key
    - Phase 1 DH group: Group 2
    - Phase 1 Encryption: 3DES
    - Phase 1 Authentication: SHA1
    - Phase 1 SA Life Time: 28800
    - Perfect Forward Secrecy: true
    - Phase 2 DH group: Group 2

- Phase 2 Encryption: 3DES
- Phase 2 Authentication: SHA1
- Phase 2 SA Life Time: 3600
- Preshared Key: 1234567890
- **Advanced**
  - Aggressive Mode: true
  - Compress(Support IP Payload Compression Protocol(IPComp)): false
  - Dead Peer Detection(DPD): false
  - NAT Traversal: true
  - Press *Save* to accept the changes.

Device 2 Device Tunnel

**Add New Tunnel**

Tunnel Number	<input type="text" value="2"/>
Tunnel Name	<input type="text" value="test"/>
Enable	<input checked="" type="checkbox"/>

---

**Local Group Setup**

Local Security Gateway Type	<input type="text" value="IP Only"/>
IP Address	<input type="text" value="172.30.147.96"/>
Local Security Group Type	<input type="text" value="Subnet"/>
IP Address	<input type="text" value="192.168.10.0"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>

---

**Remote Group Setup**

Remote Security Gateway Type	<input type="text" value="IP Only"/>
IP Address	<input type="text" value="150.160.170.1"/>
Remote Security Group Type	<input type="text" value="Subnet"/>
IP Address	<input type="text" value="10.10.10.0"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>

Figure 97 - IPSEC configuration page I for GWR Router

**IPSec Setup**

Keying Mode: IKE with Preshared key

Phase 1 DH Group: Group2

Phase 1 Encryption: 3DES

Phase 1 Authentication: SHA1

Phase 1 SA Life Time: 28800 seconds

Perfect Forward Secrecy:

Phase 2 DH Group: Group2

Phase 2 Encryption: 3DES

Phase 2 Authentication: SHA1

Phase 2 SA Life Time: 3600 seconds

Preshared Key: 1234567890

---

**Advanced**

Aggressive Mode

Compress (Support IP Payload Compression Protocol (IPComp))

Dead Peer Deection (DPD)   sec

NAT Traversal

Back
Reload
Save

Figure 98 - IPSec configuration page II for GWR Router

- Click **Start** button on **Internet Protocol Security** page to initiate IPSEC tunnel.

**geneko**  
HARDWARE
GWR ROUTER - CONFIGURATION CONSOLE

**Internet Protocol Security**

**Summary**

Tunnels Used: 1  
Tunnels Available: 5

Add New Tunnel

No.	Name	Enabled	Status	Enc/Auth/Grp	Advanced Setup	Local Group	Remote Group	Remote Gateway	Action
2	test	yes	started	Ph1: 3DES/SHA1/2 Ph2: 3DES/SHA1/2	A/N	192.168.10.0 255.255.255.0	10.10.10.0 255.255.255.0	150.160.170.1	<a href="#">Delete</a> <a href="#">Edit</a>

\* Reducing the MTU size on the client side, can help eliminate some connectivity problems occurring at the protocol level  
 \*\* Recommended MTU size on client side 1300  
 \*\*\* Press Refresh button to re-check IPSec tunnels' status  
 \*\*\*\* Tunnel status description:  
 started - ipsec is running and tunnel's waiting for other end to connect  
 established - tunnel is up  
 deleted - tunnel is down  
 stopped - ipsec is not running or tunnel is not enabled

Start
Stop
Refresh

Copyright © 2008 Geneko. All rights reserved.  
<http://www.geneko.rs/>

Figure 99 - IPSec start/stop page for GWR Router

- On the device connected on GWR router setup default gateway 192.168.10.1.

The Juniper SSG firewall configuration:

**Step1 - Create New Tunnel Interface**

- Click Interfaces on Network Tab.




Figure 100 - Network Interfaces (list)

- Bind New tunnel interface to Untrust interface (outside int – with public IP address).
- Use unnumbered option for IP address configuration.




Figure 101 - Network Interfaces (edit)

Step 2 - Create New VPN IPSEC tunnel

- Click *VPNs* in main menu. To create new gateway click *Gateway* on *AutoKey Advanced* tab.




Figure 102 - AutoKey Advanced Gateway

- Click *New* button. Enter gateway parameters:
  - **Gateway name:** TestGWR
  - **Security level:** Custom
  - **Remote Gateway type:** Dynamic IP address( because your GWR router are hidden behind Mobile operator router’s (firewall) NAT)
  - **Peer ID:** 172.30.147.96
  - **Presharedkey:** 1234567890
  - **Local ID:** 150.160.170.1

VPNs > AutoKey Advanced > Gateway > Edit

SSG140RBGE

Juniper  
NETWORKS

SSG-140

Home

Configuration

Network

Screening

Policies

MCast Policies

VPNs

AutoKey IKE

AutoKey Advanced

Gateway

P1 Proposal

P2 Proposal

XAuth Settings

VPN Groups

Manual Key

L2TP

Monitor Status

Objects

Reports

Wizards

Help

Logout

Toggle Menu

Gateway Name: TestGWR

Security Level:  Standard  Compatible  Basic  Custom

Remote Gateway Type

Static IP Address IP Address/Hostname: \_\_\_\_\_

Dynamic IP Address Peer ID: 172.30.147.96

Dialup User User: None

Dialup User Group Group: None

Preshared Key: \*\*\*\*\* Use As Seed:

Local ID: 150.160.170.1 (optional)

Outgoing Interface: ethernet0/2

OK Cancel Advanced

Figure 103 - Gateway parameters

- Click *Advanced* button.
  - **Security level - User Defined:** custom
  - **Phase 1 proposal:** pre-g2-3des-sha
  - **Mode:** Aggressive(must be aggressive because of NAT)
  - **Nat-Traversal:** enabled
  - Click *Return* and *OK*.




Figure 104 - Gateway advanced parameters

### Step 3 - Create AutoKey IKE

- Click *VPNs* in main menu. Click *AutoKey IKE*.
- Click *New* button.




Figure 105 - AutoKey IKE

AutoKey IKE parameters are:

- **VPNname:** TestGWR
- **Security level:** Custom
- **Remote Gateway:** Predefined
- Choose VPN Gateway from step 2




Figure 106 - AutoKey IKE parameters

- Click *Advanced* button.
  - **Security level - User defined:** custom
  - **Phase 2 proposal:** pre-g2-3des-sha
  - **Bind to - Tunnel interface:** tunnel.3(from step 1)
  - **Proxy ID:** Enabled
  - **LocalIP/netmask:** 10.10.10.0/24
  - **RemoteIP/netmask:** 192.168.10.0/24
  - Click *Return* and *OK*.

Figure 107 - AutoKey IKE advanced parameters

#### Step 4 - Routing

- Click *Destination* tab on *Routing* menu.
- Click *New* button. Routing parameters are:
  - **IP Address:** 192.168.10.0/24
  - **Gateway:** tunnel.3(tunnel interface from step 1)
  - Click **OK**.

The screenshot shows the configuration page for a virtual router on a Juniper SSG-140. The breadcrumb trail is 'Network > Routing > Routing Entries > Configuration'. The page title is 'SSG-140RBGE'. The configuration fields are as follows:

- Virtual Router Name:** trust-vr
- IP Address/Netmask:** 192.168.10.0 / 0
- Next Hop:**
  - Virtual Router: untrust-vr
  - Gateway
- Gateway Configuration (when Gateway is selected):**
  - Interface:** tunnel.3
  - Gateway IP Address:** 0.0.0.0
  - Permanent:**
  - Tag:** 0
- Metric:** 1
- Preference:** 20

Buttons for 'OK' and 'Cancel' are located at the bottom right of the configuration area.

Figure 108 - Routing parameters

#### Step 4 - Policies

- Click *Policies* in main menu.
- Click *New* button (from Untrust to trust zone)
  - **Source Address:** 192.168.10.0/24
  - **Destination Address:** 10.10.10.0/24
  - **Services:** Any
- Click *OK*.




Figure 109 - Policies from untrust to trust zone

- Click *Policies* in main menu.
- Click *New* button (from trust to untrust zone)
  - **Source Address:** 10.10.10.0/24
  - **Destination Address:** 192.168.10.0/24
  - **Services:** Any
- Click *OK*.




Figure 110 - Policies from trust to untrust zone

## Appendix

### A. How to Achieve Maximum Signal Strength with GWR Router?

The best throughput comes from placing the device in an area with the greatest Received Signal Strength Indicator (RSSI). RSSI is a measurement of the Radio Frequency (RF) signal strength between the base station and the mobile device, expressed in dBm. The better the signal strength, the less data retransmission and, therefore, better throughput.

RSSI information is available from several sources:

- The LEDs on the device give a general indication.
- Via the GWR Router local user interface.

Signal strength LED indicator:

- -101 or less dBm = Unacceptable (running LED)
- -100 to -91 dBm = Weak (1 LED)
- -90 to -81 dBm = Moderate (2 LED)
- -80 to -75 dBm = Good (3 LED)
- -74 or better dBm = Excellent (4 LED)
- 0 is not known or not detectable (running LED).

#### *Antenna placement*

Placement can drastically increase the signal strength of a cellular connection. Often times, just moving the router closer to an exterior window or to another location within the facility can result in optimum reception.

Another way of increasing throughput is by physically placing the device on the roof of the building (in an environmentally safe enclosure with proper moisture and lightning protection).

- Simply install the GWR Router outside the building and run an RJ-45 Ethernet cable to your switch located in the building.
- Keep antenna cable away from interferers (AC wiring).

#### *Antenna Options*

Once optimum placement is achieved, if signal strength is still not desirable, you can experiment with different antenna options. Assuming you have tried a standard antenna, next consider:

- Check your antenna connection to ensure it is properly attached.
- High gain antenna, which has higher dBm gain and longer antenna. Many cabled antennas require a metal ground plane for maximum performance. The ground plane typically should have a diameter roughly twice the length of the antenna.

**NOTE: Another way of optimizing throughput is by sending non-encrypted data through the device. Application layer encryption or VPN put a heavy toll on bandwidth utilization. For example, IPsec ESP headers and trailers can add 20-30% or more overhead.**

B. Mobile operator GPRS settings

<b>Australia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Optus	internet	[blank]	[blank]	DNS: 202.139.83.3, 192.65.91.129
Telstra	telstra.internet	[blank]	[blank]	DNS: 139.130.4.4, 203.50.170.2
Three	3netaccess	a	a	DNS: 202.124.68.130, 202.124.76.66
Vodafone	vfinternet.au	[blank]	[blank]	DNS: 192.189.54.33, 210.80.58.3
<b>Austria</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Connect Austria ONE OneNet	web.one.at	[user specific]	[user specific]	DNS: 194.24.128.100, 194.24.128.102
Max Online	gprsinternet	GPRS	[blank]	DNS: 213.162.64.1, 213.162.64.2
Max Online Business	business.gprsinternet	GPRS	[blank]	DNS: 213.162.64.1, 213.162.64.2
Max Online Metro	gprsmetro	GPRS	[blank]	DNS: 213.162.64.1, 213.162.64.2
Mobilkom A1	A1.net	<a href="mailto:gprs@a1plus.at">gprs@a1plus.at</a>	[blank]	DNS: 194.48.124.200, 194.48.139.254
tele.ring	web	<a href="mailto:web@telering.at">web@telering.at</a>	web	DNS: 212.95.31.11, 212.95.31.35
<b>Belgium</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Mobistar	web.pro.be	mobistar	mobistar	DNS: 212.65.63.10, 212.65.63.145
Proximus	internet.proximus.be	[blank]	[blank]	DNS: 195.238.2.21, 195.238.2.22
Orange / BASE	orangeinternet	[blank]	[blank]	-
<b>Brasil</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Claro	claro.com.br	claro	claro	-
TIM	tim.br	tim	tim	-
<b>Canada</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Rogers AT&T (Internet)	internet.com	wapuser1	wap	-
Rogers AT&T (VPN)	vpn.com	wapuser1	wap	-

Fido Microcell	internet.fido.ca	fido	fido	DNS: 204.92.15.211
<b>China</b>				
Operator	GPRS APN	Username	Password	Optional Settings
China Mobile	cmnet	[blank]	[blank]	-
China Unicom	[none]	[blank]	[blank]	DNS: 10.0.2.100
<b>Croatia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
VIPNET Start	gprs0.vipnet.hr	38591	38591	-
VIPNET Pro	gprs5.vipnet.hr	38591	38591	-
<b>Czech Republic</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Cesky Mobil (contract)	internet	[blank]	[blank]	DNS: 212.67.64.2
Cesky Mobil (prepaid)	cinternet	[blank]	[blank]	DNS: 212.67.64.2
Eurotel (contract)	internet	[blank]	[blank]	DNS: 160.218.10.200, 160.218.43.200
Eurotel Go	gointernet	[blank]	[blank]	DNS: 160.218.10.201, 194.228.2.1
Oscar (contract)	internet	[blank]	[blank]	DNS: 217.77.161.130, 217.77.161.131
Oscar (Oskarta)	ointernet	[blank]	[blank]	DNS: 217.77.161.130, 217.77.161.131
T-Mobile	internet.t-mobile.cz	[blank]	[blank]	DNS: 62.141.0.1, 62.141.0.2
<b>Denmark</b>				
Operator	GPRS APN	Username	Password	Optional Settings
TDC	internet	[blank]	[blank]	DNS: 193.162.146.9, 193.162.153.31
Sonofon	[blank]	[blank]	[blank]	DNS: 212.88.64.14, 212.88.64.15
Orange DK	web.orange.dk	[blank]	[blank]	DNS: 212.97.206.131, 212.97.206.161
<b>Egypt</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Click Vodafone	internet.vodafone.net	internet	internet	-
MobiNil	mobinilweb	[blank]	[blank]	-
<b>Estonia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
EMT	internet.emt.ee	[blank]	[blank]	DNS: 217.71.33.200, 217.71.32.20
RLE	internet	[blank]	[blank]	-
<b>Finland</b>				
Operator	GPRS APN	Username	Password	Optional Settings

Dna	internet	[blank]	[blank]	DNS: 217.78.192.78, 217.78.192.22
Radiolinja	internet	[blank]	[blank]	DNS: 213.161.33.200, 193.185.210.10
Sonera	internet	[blank]	[blank]	DNS: 192.89.123.230, 192.89.123.231
<b>France</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Bouygues	ebouygtel.com	[blank]	[blank]	DNS: 62.201.119.99, 62.201.159.99
Bouygues (B2Bouygtel)	b2bouygtel.com	[blank]	[blank]	DNS: 62.201.119.99
SFR	websfr	[blank]	[blank]	DNS: 172.20.2.10, 194.6.128.4
Orange Pro	orange.fr	orange	orange	DNS: 194.051.003.056, 194.051.003.076
Orange Perso	orange	orange	orange	DNS: 194.051.003.056, 194.051.003.076
Orange MIB	orange-mib	mportail	mib	Proxy: 172.16.2.8:8000
<b>Germany</b>				
Operator	GPRS APN	Username	Password	Optional Settings
D2 Vodafone	web.vodafone.de	[any]	[any]	DNS: 139.7.30.125, 139.7.30.126
E-Plus	internet.eplus.de	eplus	gprs	DNS: 212.023.97.2, 212.23.97.3
D1 T-Mobile	internet.t-d1.de	td1	gprs	DNS: 193.254.160.1
Quam	quam.de	quam	quam	-
O2 (Viag Interkom)	internet	[blank]	[blank]	DNS: 195.182.096.28, 195.182.96.61
<b>Greece</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Telestet	gnet.b-online.gr	your phone number	24680	DNS: 212.152.79.19, 212.152.79.20
Vodafone GR	internet.vodafone.gr	[blank]	[blank]	DNS: 213.249.17.10, 213.249.17.11
Cosmote	internet	[blank]	[blank]	DNS: 195.167.065.194
<b>Hongkong</b>				
Operator	GPRS APN	Username	Password	Optional Settings
CSL	hkcs1 or internet	[blank]	[blank]	DNS: 202.84.255.1, 203.116.254.150
New World	internet	[blank]	[blank]	-

Orange	web.orangehk.com	[blank]	[blank]	-
People	internet	[blank]	[blank]	-
SmarTone	internet	[blank]	[blank]	DNS: 202.140.96.51, 202.140.96.52
Sunday	internet	[blank]	[blank]	-
<b>Hungary</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Pannon (contract)	net	[blank]	[blank]	DNS: 193.225.155.254, 194.149.0.157
Pannon (flat rate)	netx	[blank]	[blank]	DNS: 193.225.155.254, 194.149.0.157
Vodafone (prepaid)	vitamax.snet.internet.net or internet.vodafone.net	[blank]	[blank]	DNS: 80.244.97.30, 80.244.96.1
Vodafone (contract)	standardnet.vodafone.hu or internet.vodafone.net	[blank]	[blank]	DNS: 80.244.97.30, 80.244.96.1
Westel (contract)	internet	wap or user specific	wap or user specific	DNS: 194.176.224.3, 194.176.224.1
<b>India</b>				
Operator	GPRS APN	Username	Password	Optional Settings
AirTel	airtelgprs.com	[blank]	[blank]	-
BPL	bplgprs.com	bplmobile	[blank]	DNS: 202.169.145.34, 202.169.129.40
Orange	portalmms	[blank]	[blank]	DNS: 10.11.206.51, 10.11.206.50
<b>Indonesia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
IM3	www.indosat-m3.net	gprs	im3	-
Indosat	satelindogprs.com	[blank]	[blank]	DNS: 202.152.162.66, 202.152.162.67
<b>Ireland</b>				
Operator	GPRS APN	Username	Password	Optional Settings
O2 (contract)	open.internet	gprs	gprs	DNS: 62.40.32.33, 62.40.32.34
O2 (prepaid)	pp.internet	gprs	gprs	DNS: 62.40.32.33, 62.40.32.34
Vodafone	isp.vodafone.ie	vodafone	vodafone	-
<b>Israel</b>				
Operator	GPRS APN	Username	Password	Optional Settings

Cellcom	internetg	[blank]	[blank]	-
MTC-Vodafone	apn01	[blank]	[blank]	DNS: 10.10.10.30
Orange	internet	[blank]	[blank]	-
<b>Italy</b>				
Operator	GPRS APN	Username	Password	Optional Settings
BLU Contratto	INTERNET	[blank]	[blank]	DNS: 212.17.192.49, 212.17.192.49
BLU Prepagata	PINTERNET	[blank]	[blank]	DNS: 212.17.192.49, 212.17.192.49
Vodafone Omnitel	web.omnitel.it	[blank]	[blank]	DNS: 194.185.97.134
TIM	uni.tim.it	[blank]	[blank]	DNS: 213.230.155.94, 213.230.130.222
Wind	internet.wind	[blank]	[blank]	DNS: 212.245.255.2
<b>Japan</b>				
Operator	GPRS APN	Username	Password	Optional Settings
J-Phone (Vodafone)	phone	j@phone	jphone	-
<b>Lithuania</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Bite GSM	banga	[blank]	[blank]	DNS: 213.226.131.131, 193.219.32.13
Omnitel Lithuania	gprs.omnitel.net	[blank]	[blank]	DNS: 194.176.32.129, 195.22.175.1
<b>Luxembourg</b>				
Operator	GPRS APN	Username	Password	Optional Settings
LUXGSM	web.pt.lu	[blank]	[blank]	DNS: 194.154.192.101, 194.154.192.102
VOXmobile	vox.lu	-	-	-
Tango	internet	tango	tango	-
<b>Macedonian</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Mobimak	internet	internet	mobimak	-
<b>Malaysia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
DIGI	diginet	[blank]	[blank]	DNS: 203.92.128.131, 203.92.128.132
Maxis	internet.gprs.maxis	[blank]	[blank]	DNS: 202.75.129.101, 10.216.4.21
Timecel	timenet.com.my	[blank]	[blank]	DNS: 203.121.16.85, 203.121.16.120
TM Touch	internet	[blank]	[blank]	DNS: 202.188.0.133

<b>Mexico</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
Telcel	internet.itelcel.com	webgprs	webgprs2002	-
<b>Netherlands</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
KPN Mobile	internet	KPN or [blank]	gprs or [blank]	DNS: 62.133.126.28, 62.133.126.29
O2	internet	[blank]	[blank]	-
Telfort	internet	[blank]	[blank]	-
T-Mobile	internet or internet-act	t-mobile or [blank]	t-mobile or [blank]	DNS: 193.79.237.39, 193.79.242.39
Vodafone (normal)	web.vodafone.nl	vodafone	vodafone	-
Vodafone (business)	office.vodafone.nl	vodafone	vodafone	-
<b>New Zeeland</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
Vodafone	www.vodafone.net.nz	-	-	-
<b>Norway</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
Telenor Mobil	internet	[blank]	[blank]	-
Netcom	internet.netcom.no	[blank]	[blank]	DNS: 212.45.118.43, 212.45.118.44
<b>Poland</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
ERA	erainternet	erainternet	erainternet	DNS: 213.158.194.1
Idea	www.idea.pl	idea	idea	DNS: 194.9.223.79, 194.204.159.1
Plus GSM / Polkomtel	www.plusgsm.pl	[blank]	[blank]	DNS: 212.2.96.51, 212.2.96.52
<b>Phillipines</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
Globe	www.globe.com.ph	globe	globe	DNS: 203.127.225.10, 203.127.225.11
Smart	internet	[blank]	[blank]	DNS: 202.57.96.3, 202.57.96.4
Sun Cellular	minternet	[blank]	[blank]	[blank]
<b>Portugal</b>				
<b>Operator</b>	<b>GPRS APN</b>	<b>Username</b>	<b>Password</b>	<b>Optional Settings</b>
Optimus	internet	[blank]	[blank]	DNS: 194.79.69.129
TMN	internet	[blank]	[blank]	DNS: 194.65.3.20, 194.65.3.21
Vodafone	internet.vodafone.pt	[blank]	[blank]	DNS: 212.18.160.133,

(Telcel)				212.18.160.134
<b>Russia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
BeeLine	internet.beeline.ru	beeline	beeline	DNS: 194.190.195.66, 194.190.192.34
Megafon (NWGSM)	internet.nw	[blank]	[blank]	-
MTS	internet.mts.ru	mts	mts	DNS: 213.87.0.1, 213.87.1.1
PrimTel	internet.printel.ru	[blank]	[blank]	-
<b>Serbia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Mobtel Srbija	internet	mobtel	gprs	DNS: 217.65.192.1
Telekom Srbija	gprsinternet	mts	064	DNS: 195.178.38.3
VIP Mobile Srbija	vipmobile	vipmobile	vipmobile	-
<b>Singapore</b>				
Operator	GPRS APN	Username	Password	Optional Settings
M1	mobilenet or sunsurf	[blank]	[blank]	DNS: 202.79.64.21, 202.79.64.26
SingTel	internet	[blank]	[blank]	DNS: 165.21.100.88, 165.21.83.88
Starhub	shwapint	[blank]	[blank]	DNS: 203.116.1.78, 203.116.254.150
<b>Slovakia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Eurotel	internet	[blank]	[blank]	-
Orange	internet	jusernejm	pasvord	-
<b>Slovenia</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Mobitel	internet	[blank]	[blank]	DNS: 193.189.160.11, 193.189.160.12
Si.mobil	internet.si.mobil	[blank]	[blank]	DNS: 80.95.225.230, 80.95.225.231
<b>South Africa</b>				
Operator	GPRS APN	Username	Password	Optional Settings
MTN	myMTN			-
Cell-c	internet	Cellcis	Cellcis	-
<b>Spain</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Amena	internet	CLIENTE	AMENA	DNS: 213.143.33.8, 213.143.32.20
Telefonica	movistar.es	movistar	movistar	DNS: 94.179.001.100,

(Movistar)				194.179.001.101
Vodafone (Airtel)	airtelnet.es	vodafone	vodafone	DNS: 212.73.32.3, 212.73.32.67
<b>Sweden</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Telia	online.telia.se	[blank]	[blank]	-
Tele2	isplnk1.swip.net	gprs	internet	-
Vodafone Europolitan	internet.vodafone.net	[blank]	[blank]	-
<b>Switzerland</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Orange	internet	[blank]	[blank]	DNS: 213.55.128.1, 213.55.128.2
Sunrise	internet	internet	internet	DNS: 212.35.35.35, 212.35.35.5
Swisscom	gprs.swisscom.ch	[blank]	[blank]	DNS: 164.128.36.34, 164.128.76.39
<b>Taiwan</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Chunghwa Telekom	emome or internet	[blank]	[blank]	DNS: 10.1.1.1
Far EasTone	fetnet01	[blank]	[blank]	DNS: 210.241.199.199
KG Telecom	internet	[blank]	[blank]	-
Taiwan Cellular	internet	[blank]	[blank]	-
<b>Thailand</b>				
Operator	GPRS APN	Username	Password	Optional Settings
AIS	internet	[blank]	[blank]	DNS: 202.183.255.20, 202.183.255.21
DTAC	www.dtac.co.th	[blank]	[blank]	DNS: 203.155.33.1, 203.44.144.33
<b>Turkey</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Aria	aycell	[user specific]	[user specific]	DNS: 212.156.4.1, 212.156.4.4
AVEA	internet	-	-	-
Telsim	telsim	telsim	telsim	-
Turkcell	internet	[blank] or gprs	[blank] or gprs	DNS: 212.252.168.240, 212.252.119.4
<b>UK</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Vodafone UK	Internet	web	web	-
O2 UK	mobile.o2.co.uk	web	password	DNS:

(contract)				193.113.200.200, 193.113.200.201
O2 UK (prepaid)	payandgo.o2.co.uk	payandgo	payandgo	-
Orange UK	orangeinternet	[blank]	[blank]	DNS: 158.43.192.1, 158.143.128.1
T-Mobile	general.t-mobile.uk	user	mms	-
T-Mobile (One2One)	general.t-mobile.uk	Username	one2one	-
Jersey Telecom	pepper	[blank]	[blank]	DNS: 212.9.0.135, 212.9.0.135
<b>Ukraine</b>				
Operator	GPRS APN	Username	Password	Optional Settings
Jeans	www.jeans.ua	-	-	-
UMC	www.umc.ua	-	-	-
<b>USA</b>				
Operator	GPRS APN	Username	Password	Optional Settings
AT&T (VPN)	public	-	-	-
AT&T	proxy	-	-	Gateway IP: 10.250.250.250 or blank Port: 9201 or blank
Bell Mobility	-	-	-	Gateway IP: 207.236.197.199 Port: 9203
Cellular One	cellular1wap	-	-	Gateway IP: 207.236.197.199 Port: 9203
Cincinnati Bell	wap.gocbw.com	cbw	-	Gateway IP: 216.68.79.199 Port: 9201
Cingular (former AT&T users)	proxy	-	-	Gateway IP: 10.250.250.250 or blank Port: 9201 or blank
Cingular (MediaWorks)	WAP.CINGULAR	WAP@ CINGULARGPR S .COM	CINGULAR1	-
Cingular	isp.cingular	ISPDA@CINGU LARGPRS.COM	CINGULAR1	DNS: 66.209.10.201, 66.209.10.202
Nextel/Telus	-	-	-	-
Rogers	internet.com	-	-	-
Sprint - CDMA	-	-	-	CDMA and not GPRS settings

T-Mobile (T-Zone)	wap.voicestream.com	[blank] or Your T-MOBILE Username	[blank] or Your T-MOBILE Password	-
T-Mobile (Internet)	internet2.voicestream.com	[blank]	[blank]	DNS: 216.155.175.105, 216.155.175.106
T-Mobile (VPN)	internet3.voicestream.com	[blank]	[blank]	DNS: 216.155.175.105, 216.155.175.106