

Quick Setup Guide

i-MO 310 Series *Bonding Router*



Quick Setup Guide

for the i-MO 310 Series Appliance

OptiBond™



Advanced Bandwidth
Technologies



Content

Content	2
i-MO Appliance Identification Guide	3
General Safety Guidelines for EMS Hardware Equipment.....	4
Installation Safety Guidelines and Warnings	4
Operating Temperature Warning.....	4
Product Disposal Warning	5
General Electrical Safety Warnings for EMS Hardware Equipment.....	5
Radio Frequency Interference	5
Electromagnetic Compatibility	5
AC Power Electrical Safety Guidelines.....	5
Hardware Installation Guide	6
Download or view the i-MO 310 Installation Guide online	6
Appendix A - Disposal and Recycling Information	6
WEEE EU Directive	6
Reduction of Hazardous Substances	6
Appendix B - Warranty Information	7
Obtaining Technical Assistance	8

i-MO Appliance Identification Guide

The following diagram shows the basic and optional i-MO hardware components.

1 x i-MO Appliance



Optional: Up to 3 x external aerials



Optional: Up to 3 x external aerials
Optional: Up to 3 x external aerial brackets



1 x Mains AC Adapter and UK Mains Lead



Optional - 2 x WiFi antenna
and / or
Optional: Up to 3 x external aerials

General Safety Guidelines for EMS Hardware Equipment

The following guidelines help ensure your safety and protect the hardware equipment from damage. The list of guidelines might not address all potentially hazardous situations in your working environment, so be alert and exercise good judgment at all times.

- Perform only the procedures explicitly described in this documentation. Make sure that only authorized service personnel perform other system services.
- Keep the area around the chassis clear and free from dust before, during, and after installation.
- Keep tools away from areas where people could trip over them while walking.
- Wear safety glasses if you are working under any conditions that could be hazardous to your eyes.
- Do not perform any actions that create a potential hazard to people or make the equipment unsafe.
- Never install or manipulate wiring during electrical storms.
- Never install electrical jacks in wet locations unless the jacks are specifically designed for wet environments.
- Operate the hardware equipment only when the chassis is properly grounded.
- Do not open or remove chassis covers or sheet metal parts unless instructions are provided in this documentation. Such an action could cause severe electrical shock.
- Do not push or force any objects through any opening in the chassis frame. Such an action could result in electrical shock or fire.
- Avoid spilling liquid onto the chassis or onto any hardware component. Such an action could cause electrical shock or damage the hardware equipment.
- Do not use the device where inflammables or explosives are stored, for example, in a fuel station, oil depot, or chemical plant. Otherwise, explosions or fires may occur.
- Use only the accessories supplied or authorized by the device manufacturer. Otherwise, the performance of the device may get affected, the warranty for the device or the laws and regulations related to telecommunications terminals may become null and void, or an injury may occur.
- Do not use the power adapter if its cable is damaged. Otherwise, electric shocks or fires may occur.
- Do not use the antennas if the connectors, cables, or antennas are damaged. Otherwise, radio frequency interference or electric shock may occur.

Installation Safety Guidelines and Warnings

Read the installation instructions before you connect the hardware equipment to a power source.

Operating Temperature Warning

To prevent the hardware equipment from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of 40°C. To prevent airflow restriction, allow at least 2 inches of clearance around the ventilation grilles.

Do not expose to direct sunlight.

Do not place containers of liquids on the device or allow the device to come in contact with liquids.

Do not place near or on a source of heat.

Product Disposal Warning

Disposal of this product must be handled according to all national laws and regulations.

See [Appendix A](#) for details.

General Electrical Safety Warnings for EMS Hardware Equipment

Radio Frequency Interference

You can reduce or eliminate the emission of radio frequency interference (RFI) from your site wiring by using twisted-pair network cabling with a good distribution of grounding conductors. If you must exceed the recommended distances, use a high-quality twisted-pair cable with one ground conductor for each data signal when applicable.

Electromagnetic Compatibility

If your site is susceptible to problems with electromagnetic compatibility (EMC), particularly from lightning or radio transmitters, you might want to seek expert advice. Strong sources of electromagnetic interference (EMI) can destroy the signal drivers and receivers in the router and conduct power surges over the lines into the equipment, resulting in an electrical hazard. It is particularly important to provide a properly grounded and shielded environment and to use electrical surge-suppression devices.

AC Power Electrical Safety Guidelines

The i-MO requires an AC supply of 240Volts, 50Hz and can draw a current of up to 2 Amps.

i-MO routers are shipped with a three-wire electrical cord with a grounding-type plug that fits only a grounding-type power outlet. Do not circumvent this safety feature. Equipment grounding should comply with local and national electrical codes. The power cord serves as the main disconnecting device. The socket outlet must be near the router and be easily accessible.

Hardware Installation Guide

Download or view the i-MO 310 Installation Guide online

The i-MO 310 Series Appliance hardware installation guide can be found here:



[iMO 310Series Client Installation Manual.pdf](#)

Appendix A - Disposal and Recycling Information

This device (and any included batteries) should not be disposed of as normal household garbage. Do not dispose of your device or batteries as unsorted municipal waste. The device (and any batteries) should be handed over to a certified collection point for recycling or proper disposal at the end of their life.

For more detailed information about the recycling of the device or batteries, contact your local city office, the household waste disposal service, or the retail store where you purchased this device.

WEEE EU Directive

The disposal of this device is subject to the Waste from Electrical and Electronic Equipment (WEEE) directive of the European Union. The reason for separating WEEE and batteries from other waste is to minimize the potential environmental impacts on human health of any hazardous substances that may be present.

If in any doubt, please view detailed WEEE information on the following web page from the Environment Agency's web site:

<http://www.environment-agency.gov.uk/business/topics/waste/32084.aspx>

Reduction of Hazardous Substances

This device is compliant with the EU Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH) Regulation (Regulation No 1907/2006/EC of the European Parliament and of the Council) and the EU Restriction of Hazardous Substances (RoHS) Directive (Directive 2002/95/EC of the European Parliament and of the Council). For more information about the REACH compliance of the device, visit the Web site www.ems-uk.com/certification. You are recommended to visit the Web site regularly for up-to-date information.

Appendix B - Warranty Information

EMS's Limited Warranty Statement (1-Year Warranty)

Thank you for purchasing the enclosed i-MO Appliance. The product is provided with a one year limited warranty commencing from the date of purchase.

One-Year Limited Warranty

THIS PRODUCT IS PROVIDED TO YOU UNDER THE FOLLOWING TERMS AND CONDITIONS THAT CONTAIN LIMITATIONS ON WARRANTIES AND LIABILITIES AND YOUR REMEDIES. BY USING THIS PRODUCT YOU AGREE TO THE TERMS AND CONDITIONS BELOW.

The original end-user purchaser of the enclosed i-MO Appliance (the "Product") from EMS Ltd (the "Vendor") or one of its authorized Partners, is offered with a non-transferable, limited warranty that: (a) the Product will be of good quality and free from defects in design, materials, workmanship, and manufacture under normal use and service; (b) all materials, parts, components, and other items incorporated in the Product will be new; and (c) the Product will be compliant with, and perform in accordance with, its specifications, for a period that expires one year from the original purchase date of the Product (the "Warranty Period").

During the Warranty Period, if Vendor determines that a Product is defective under a proper warranty claim, then Vendor will, at its sole discretion, either (a) pay parts and labour charges for the repair of the Product, or (b) replace the Product with a new or rebuilt unit (which unit may use refurbished parts of similar quality and functionality), provided that the defective Product is returned to a Vendor-authorized service centre for the Product, transportation charges prepaid, and is accompanied by written proof of purchase in the form of a bill of sale or receipted invoice indicating that the Product was purchased by you and is within the Warranty Period. After the Warranty Period, you are responsible for paying all parts, labour, and shipping charges. The warranty described above shall apply to all repaired or replaced Product for a period of 90 days from the date of return to you, or the balance of the Warranty Period, whichever is greater.

This limited warranty does not cover and is void with respect to: (a) Products which have been improperly installed, repaired, maintained, or modified; (b) Products which have been subjected to misuse (including using the Products with hardware which is electrically or mechanically incompatible with the Products), abuse, accident, physical damage, abnormal operation, improper handling or storage, neglect, exposure to fire, water, or excessive moisture or dampness, or extreme changes in climate or temperature; (c) Products which have been opened, repaired, modified, or altered by anyone other than Vendor or a Vendor-authorized service centre; (d) Products which have been damaged due to fire, flood, acts of God, or other acts which are not Vendor's fault and which the Product is not specified to tolerate; (e) cosmetic damage; (f) Products which have been operated outside of published maximum ratings; (g) cost of installation, removal, or re-installation of the Product; (h) signal reception problems (unless caused by a defect in material(s) or workmanship); or (i) Products on which warranty stickers or serial numbers have been removed, altered, or rendered illegible. This limited warranty is not transferable to any third party including, but not limited to, any subsequent purchaser or owner of the Products. Any transfer or resale of any of the Products will automatically terminate Vendor's warranty coverage of such Products. This limited warranty does not cover customer education, instruction, installation, set-up adjustments, or signal reception problems.

REPAIR OR REPLACEMENT, AS PROVIDED FOR UNDER THIS LIMITED WARRANTY, IS YOUR SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THIS LIMITED WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER VENDOR NOR THE ORIGINAL OWNER OF THE PRODUCT MAKE ANY OTHER REPRESENTATIONS, WARRANTIES, OR CONDITIONS OF ANY KIND, EXPRESS OR IMPLIED OR STATUTORY, WITH RESPECT TO THE PRODUCT INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.

This warranty gives you specific rights and you may also have other rights, which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion of implied warranties and conditions and do not permit the exclusion or limitation of certain damages. Therefore, the foregoing exclusions may not apply to you.

THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THIS PRODUCT IS ASSUMED BY YOU. NEITHER THE ORIGINAL OWNER OF THE PRODUCT NOR THE VENDOR NOR VENDOR'S DISTRIBUTORS, RESELLERS, SUPPLIERS, AGENTS, OFFICERS, AND DIRECTORS SHALL HAVE ANY LIABILITY TO YOU OR TO ANY OTHER PERSON OR ENTITY FOR ANY DAMAGES HOWSOEVER CAUSED INCLUDING, BUT NOT LIMITED TO, DIRECT, INDIRECT, INCIDENTAL, SPECIAL, GENERAL, CONSEQUENTIAL, PUNITIVE, OR EXEMPLARY DAMAGES WHATSOEVER INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, DAMAGES TO PROPERTY OR PERSONS, LOST OR DAMAGED DATA, OR OTHER COMMERCIAL OR ECONOMIC LOSS, EVEN IF ANY SUCH AFOREMENTIONED PERSON HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE, OR FOR CLAIMS BY ANY THIRD PARTY. MAXIMUM AGGREGATE LIABILITY OF THE AFOREMENTIONED PERSONS SHALL NOT EXCEED THE AMOUNT PAID BY YOU FOR THE PRODUCT. THE LIMITATIONS IN THIS SECTION SHALL APPLY WHETHER OR NOT THE ALLEGED BREACH, DEFAULT, NONPERFORMANCE, OR FAILURE IS A BREACH OF FUNDAMENTAL CONDITION OR TERM, OR A FUNDAMENTAL BREACH.

If any provision or term of these terms and conditions is determined to be invalid or unenforceable, the invalidity or un-enforceability of that provision or term will not affect the validity or enforceability of the remaining provisions and terms or the validity or enforceability of that provision or term in any other jurisdiction.

THIS LIMITED WARRANTY IS NOT AN ALTERNATIVE TO THE PURCHASE OF AN ANNUAL MAINTENANCE AGREEMENT. For further details of Annual Maintenance Agreement Terms & Conditions please refer to the separate Maintenance Agreement documentation provided by EMS Ltd or Authorised Partner.

Obtaining Technical Assistance

EMS Ltd provides www.ems-imo.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools by using this Web Site. Registered users (requires a valid Annual Maintenance Agreement) have complete access to the technical support resources on the www.ems-imo.com Web Site.